

MHI

TECHNICAL MANUAL

DRAFT

Manual No.'13•SRK-T-143D

INVERTER WALL MOUNTED TYPE RESIDENTIAL AIR-CONDITIONERS (Split system, air to air heat pump type)

SRK20ZM-S

25ZM-S

35ZM-S

50ZM-S




mitsubishi heavy industries, ltd.

CONTENTS

1. SPECIFICATIONS	2
2. EXTERIOR DIMENSIONS	6
(1) Indoor units	6
(2) Outdoor units	7
(3) Remote control	9
3. ELECTRICAL WIRING	10
(1) Indoor units	10
(2) Outdoor units	11
4. NOISE LEVEL	13
5. PIPING SYSTEM	17
6. RANGE OF USAGE & LIMITATIONS	19
7. CAPACITY TABLES	21
8. APPLICATION DATA	23
(1) Installation of indoor unit	23
(2) Installation of outdoor unit	27
9. OPTION PARTS	35
(1) Wired remote control (RC-E5)	35
(2) Interface kit (SC-BIKN-E)	41
(3) Super link E board (SC-ADNA-E)	45
10. TECHNICAL INFORMATION	47

■ How to read the model name



1. SPECIFICATIONS

Item			Model	SRK20ZM-S		
				Indoor unit SRK20ZM-S	Outdoor unit SRC20ZM-S	
Power source				Single phase, 220 - 240V, 50Hz		
Operation data	Nominal cooling capacity (range)		kW	2.0 (1.0 (Min.) - 2.7 (Max.))		
	Nominal heating capacity (range)		kW	2.7 (1.2 (Min.) - 3.9 (Max.))		
	Power consumption	Cooling	kW	0.44 (0.21 - 0.77)		
		Heating		0.62 (0.27 - 1.38)		
	Max power consumption			1.65		
	Running current	Cooling	A	2.5 / 2.4 / 2.3 (220/ 230/ 240 V)		
		Heating		3.2 / 3.1 / 3.0 (220/ 230/ 240 V)		
	Inrush current, max current			3.2 / 3.1 / 3.0 (220/ 230/ 240 V) Max. 9		
	Power factor	Cooling	%	79.7		
		Heating		87		
	EER	Cooling		4.55		
	COP	Heating		4.35		
	Sound power level	Cooling	dB(A)	49	59	
		Heating		52	58	
Sound pressure level	Cooling	Hi: 33 Me: 27 Lo: 24 ULo: 21		47		
	Heating	Hi: 36 Me: 31 Lo: 24 ULo: 21		46		
Silent mode sound pressure level			—			
Exterior dimensions (Height x Width x Depth)			mm	294 x 798 x 229	540 x 780(+62) x 290	
Exterior appearance (Munsell color)				Fine snow (8.0Y 9.3/0.1) near equivalent	Stucco white (4.2Y 7.5/1.1) near equivalent	
Net weight			kg	9.5	31.5	
Compressor type & Q'ty				—	RM-B5077MDE1(Rotary type) x 1	
Compressor motor (Starting method)			kW	—	0.75 (Inverter driven)	
Refrigerant oil (Amount, type)			ℓ	—	0.35 (DIAMOND FREEZE MA68)	
Refrigerant (Type, amount, pre-charge length)			kg	R410A 0.75 in outdoor unit (incl. the amount for the piping of 15m)		
Heat exchanger				Louver fins & inner grooved tubing	M fins & inner grooved tubing	
Refrigerant control				Capillary tubes + Electronic expansion valve		
Fan type & Q'ty				Tangential fan x 1	Propeller fan x 1	
Fan motor (Starting method)			W	30 x1 (Direct drive)	24 x1 (Direct drive)	
Air flow	Cooling	m³/min	Hi: 7.8 Me: 5.6 Lo: 5.3 ULo: 4.8	29.5		
	Heating		Hi: 9.8 Me: 6.3 Lo: 5.0 ULo: 4.5	25.6		
Available external static pressure			Pa	0	0	
Outside air intake				Not possible	—	
Air filter, Quality / Quantity				Polypropylene net (washable) x 2	—	
Shock & vibration absorber				Rubber sleeve (for fan motor)	Rubber sleeve (for fan motor & compressor)	
Electric heater				—	—	
Operation control	Remote control			Wireless remote control		
	Room temperature control			Microcomputer thermostat		
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green		
Safety equipments				Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Indoor fan motor error protection, Heating overload protection (High pressure control), Cooling overload protection		
Installation data	Refrigerant piping size (O.D)		mm	Liquid line : ϕ 6.35 (1/4") Gas line : ϕ 9.52 (3/8")		
	Connecting method			Flare connection	Flare connection	
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40	—	
	Insulation for piping			Necessary (Both sides), independent		
	Refrigerant line (one way) length		m	Max. 15		
	Vertical height diff. between O.U. and I.U.		m	Max. 10 (Outdoor unit is higher) / Max. 10 (Outdoor unit is lower)		
Drain hose				Hose connectable (VP 16)	Holes ϕ 20 x 2 pcs	
Drain pump, max lift height			mm	—	—	
Recommended breaker size			A	16		
L.R.A. (Locked rotor ampere)			A	3.2 / 3.1 / 3.0 (220/ 230/ 240 V)		
Interconnecting wires		Size x Core number		1.5mm ² x 4 cores (Including earth cable) / Terminal block (Screw fixing type)		
IP number				IPX0	IPX4	
Standard accessories				Mounting kit, Clean filter (Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1)		
Option parts				Interface kit (SC-BIKN-E)		
Note (1) The data are measured at the following conditions.						
The pipe length is 7.5m.						
Operation	Item	Indoor air temperature		Outdoor air temperature		Standards
		DB	WB	DB	WB	
	Cooling	27°C	19°C	35°C	24°C	ISO5151-T1
	Heating	20°C	—	7°C	6°C	
(2) This air-conditioner is manufactured and tested in conformity with the ISO.						
(3) Sound level indicates the value in an anechoic chamber. During operation these value are somewhat higher due to ambient conditions.						
(4) Select the breaker size according to the own national standard.						

Item			Model	SRK25ZM-S	
				Indoor unit SRK25ZM-S	Outdoor unit SRC25ZM-S
Power source			Single phase, 220 - 240V, 50Hz		
Operation data	Nominal cooling capacity (range)		kW	2.5 (1.0 (Min.) - 2.9 (Max.))	
	Nominal heating capacity (range)		kW	3.2 (1.2 (Min.) - 4.2 (Max.))	
	Power consumption	Cooling	kW	0.62 (0.21 - 0.88)	
		Heating		0.80 (0.27 - 1.36)	
	Max power consumption			1.65	
	Running current	Cooling	A	3.2 / 3.1 / 3.0 (220/ 230/ 240 V)	
		Heating		4.0 / 3.8 / 3.7 (220/ 230/ 240 V)	
	Inrush current, max current			4.0 / 3.8 / 3.7 (220/ 230/ 240 V) Max. 9	
	Power factor	Cooling	%	87	
		Heating		91.5	
	EER	Cooling		4.03	
	COP	Heating		4.00	
	Sound power level	Cooling	dB(A)	50	
		Heating		55	
		Cooling		Hi: 34 Me: 28 Lo: 24 ULo: 21	
		Heating		Hi: 39 Me: 31 Lo: 24 ULo: 21	
Silent mode sound pressure level			—		
Exterior dimensions (Height x Width x Depth)		mm	294 x 798 x 229		
Exterior appearance (Munsell color)			Fine snow (8.0Y 9.3/0.1) near equivalent		
Net weight		kg	9.5		
Compressor type & Q'ty			—		
Compressor motor (Starting method)		kW	—		
Refrigerant oil (Amount, type)		ℓ	—		
Refrigerant (Type, amount, pre-charge length)		kg	R410A 0.75 in outdoor unit (incl. the amount for the piping of 15m)		
Heat exchanger			Louver fins & inner grooved tubing		
Refrigerant control			Capillary tubes + Electronic expansion valve		
Fan type & Q'ty			Tangential fan x 1		
Fan motor (Starting method)		W	30 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 7.9 Me: 6.0 Lo: 5.3 ULo: 5.0		
	Heating		Hi: 10.6 Me: 6.5 Lo: 5.1 ULo: 4.6		
Available external static pressure		Pa	0		
Outside air intake			Not possible		
Air filter, Quality / Quantity			Polypropylene net (washable) x 2		
Shock & vibration absorber			Rubber sleeve (for fan motor)		
Electric heater			—		
Operation control	Remote control		Wireless remote control		
	Room temperature control		Microcomputer thermostat		
	Operation display		RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green		
Safety equipments			Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Indoor fan motor error protection, Heating overload protection (High pressure control), Cooling overload protection		
Installation data	Refrigerant piping size (O.D)	mm	Liquid line : ϕ 6.35 (1/4") Gas line : ϕ 9.52 (3/8")		
	Connecting method		Flare connection		
	Attached length of piping	m	Liquid line : 0.53 / Gas line : 0.40		
	Insulation for piping		Necessary (Both sides), independent		
	Refrigerant line (one way) length	m	Max. 15		
	Vertical height diff. between O.U. and I.U.	m	Max. 10 (Outdoor unit is higher) / Max. 10 (Outdoor unit is lower)		
Drain hose			Hose connectable (VP 16)		
Drain pump, max lift height		mm	—		
Recommended breaker size		A	16		
L.R.A. (Locked rotor ampere)		A	4.0 / 3.8 / 3.7 (220/ 230/ 240 V)		
Interconnecting wires	Size x Core number		1.5mm² x 4 cores (Including earth cable) / Terminal block (Screw fixing type)		
IP number			IPX0		
Standard accessories			Mounting kit, Clean filter (Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1)		
Option parts			Interface kit (SC-BIKN-E)		
Note (1) The data are measured at the following conditions.			The pipe length is 7.5m.		
Operation	Item	Indoor air temperature		Outdoor air temperature	
		DB	WB	DB	WB
	Cooling	27°C	19°C	35°C	24°C
	Heating	20°C	—	7°C	6°C
ISO5151-T1					
(2) This air-conditioner is manufactured and tested in conformity with the ISO.					
(3) Sound level indicates the value in an anechoic chamber. During operation these value are somewhat higher due to ambient conditions.					
(4) Select the breaker size according to the own national standard.					


Item			Model	SRK35ZM-S	
				Indoor unit SRK35ZM-S	Outdoor unit SRC35ZM-S
Power source				Single phase, 220 - 240V, 50Hz	
Operation data	Nominal cooling capacity (range)		kW	3.5 (1.0 (Min.) - 3.8 (Max.))	
	Nominal heating capacity (range)		kW	4.0 (1.3 (Min.) - 4.8 (Max.))	
	Power consumption	Cooling	kW	1.01 (0.21 - 1.24)	
		Heating		1.00 (0.29 - 1.45)	
	Max power consumption			1.65	
	Running current	Cooling	A	4.9 / 4.7 / 4.5 (220/ 230/ 240 V)	
		Heating		4.9 / 4.7 / 4.5 (220/ 230/ 240 V)	
	Inrush current, max current			4.9 / 4.7 / 4.5 (220/ 230/ 240 V) Max. 9	
	Power factor	Cooling	%	93.4	
		Heating		92.5	
	EER	Cooling		3.47	
	COP	Heating		4.00	
	Sound power level	Cooling	dB(A)	58	
		Heating		59	
		Cooling		Hi: 42 Me: 32 Lo: 26 ULo: 22	
		Heating		Hi: 43 Me: 37 Lo: 25 ULo:22	
Silent mode sound pressure level			—		
Exterior dimensions (Height x Width x Depth)		mm	294 x 798 x 229		
Exterior appearance (Munsell color)			Fine snow (8.0Y 9.3/0.1) near equivalent		
Net weight		kg	9.5		
Compressor type & Q'ty			—		
Compressor motor (Starting method)		kW	—		
Refrigerant oil (Amount, type)		ℓ	—		
Refrigerant (Type, amount, pre-charge length)		kg	R410A 1.05 in outdoor unit (incl. the amount for the piping of 15m)		
Heat exchanger			Louver fins & inner grooved tubing		
Refrigerant control			Capillary tubes + Electronic expansion valve		
Fan type & Q'ty			Tangential fan x 1		
Fan motor (Starting method)		W	30 x1 (Direct drive)		
Air flow	Cooling	m³/min	Hi: 10.1 Me: 6.4 Lo: 5.4 ULo: 5.0		
	Heating		Hi: 12.8 Me: 9.4 Lo: 6.1 ULo: 4.8		
Available external static pressure		Pa	0		
Outside air intake			Not possible		
Air filter, Quality / Quantity			Polypropylene net (washable) x 2		
Shock & vibration absorber			Rubber sleeve (for fan motor)		
Electric heater			—		
Operation control	Remote control		Wireless remote control		
	Room temperature control		Microcomputer thermostat		
	Operation display		RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green		
Safety equipments			Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Indoor fan motor error protection, Heating overload protection (High pressure control), Cooling overload protection		
Installation data	Refrigerant piping size (O.D)		mm	Liquid line : ϕ 6.35 (1/4") Gas line : ϕ 9.52 (3/8")	
	Connecting method			Flare connection	
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40	
	Insulation for piping			Necessary (Both sides), independent	
	Refrigerant line (one way) length		m	Max. 15	
	Vertical height diff. between O.U. and I.U.		m	Max. 10 (Outdoor unit is higher) / Max. 10 (Outdoor unit is lower)	
Drain hose			Hose connectable (VP 16)		
Drain pump, max lift height		mm	—		
Recommended breaker size		A	16		
L.R.A. (Locked rotor ampere)		A	4.9 / 4.7 / 4.5 (220/ 230/ 240 V)		
Interconnecting wires		Size x Core number	1.5mm² x 4 cores (Including earth cable) / Terminal block (Screw fixing type)		
IP number			IPX0		
Standard accessories			Mounting kit, Clean filter (Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1)		
Option parts			Interface kit (SC-BIKN-E)		
Note (1) The data are measured at the following conditions.					
The pipe length is 7.5m.					
Operation	Item	Indoor air temperature		Outdoor air temperature	
		DB	WB	DB	WB
	Cooling	27°C	19°C	35°C	24°C
	Heating	20°C	—	7°C	6°C
Standards					
ISO5151-T1					
(2) This air-conditioner is manufactured and tested in conformity with the ISO.					
(3) Sound level indicates the value in an anechoic chamber. During operation these value are somewhat higher due to ambient conditions.					
(4) Select the breaker size according to the own national standard.					

Item			Model	SRK50ZM-S	
				Indoor unit SRK50ZM-S	Outdoor unit SRC50ZM-S
Power source				Single phase, 220 - 240V, 50Hz	
Operation data	Nominal cooling capacity (range)		kW	5.0 (1.6 (Min.) - 5.5 (Max.))	
	Nominal heating capacity (range)		kW	5.8 (1.6 (Min.) - 6.6 (Max.))	
	Power consumption	Cooling	kW	1.55 (0.40 - 2.20)	
		Heating		1.59 (0.42 - 2.10)	
	Max power consumption			2.68	
	Running current	Cooling	A	7.1 / 6.8 / 6.5 (220/ 230/ 240 V)	
		Heating		7.3 / 7.0 / 6.7 (220/ 230/ 240 V)	
	Inrush current, max current			7.3 / 7.0 / 6.7 (220/ 230/ 240 V) Max. 14	
	Power factor	Cooling	%	99	
		Heating		99	
	EER	Cooling		3.23	
	COP	Heating		3.65	
	Sound power level	Cooling	dB(A)	60	
		Heating		61	
	Sound pressure level	Cooling		Hi: 46 Me: 37 Lo: 28 ULo: 25	
		Heating		Hi: 45 Me: 37 Lo: 31 ULo:27	
Silent mode sound pressure level			—		
Exterior dimensions (Height x Width x Depth)			mm	294 x 798 x 229	
Exterior appearance (Munsell color)				Fine snow (8.0Y 9.3/0.1) near equivalent	
Net weight			kg	9.5	
Compressor type & Q'ty				—	
Compressor motor (Starting method)			kW	—	
Refrigerant oil (Amount, type)			ℓ	—	
Refrigerant (Type, amount, pre-charge length)			kg	R410A 1.35 in outdoor unit (incl. the amount for the piping of 15m)	
Heat exchanger				Louver fins & inner grooved tubing	
Refrigerant control				Capillary tubes + Electronic expansion valve	
Fan type & Q'ty				Tangential fan x 1	
Fan motor (Starting method)			W	30 x1 (Direct drive)	
Air flow	Cooling	m³/min	Hi: 11.3 Me: 7.8 Lo: 6.0 ULo: 5.3		
	Heating		Hi: 13.5 Me: 10.2 Lo: 7.5 ULo: 6.2		
Available external static pressure			Pa	0	
Outside air intake				Not possible	
Air filter, Quality / Quantity				Polypropylene net (washable) x 2	
Shock & vibration absorber				Rubber sleeve (for fan motor)	
Electric heater				—	
Operation control	Remote control			Wireless remote control	
	Room temperature control			Microcomputer thermostat	
	Operation display			RUN: Green, TIMER: Yellow, HI POWER: Green, 3D AUTO: Green	
Safety equipments				Compressor overheat protection, Overcurrent protection, Frost protection, Serial signal error protection, Indoor fan motor error protection, Heating overload protection (High pressure control), Cooling overload protection	
Installation data	Refrigerant piping size (O.D)		mm	Liquid line : ϕ 6.35 (1/4") Gas line : ϕ 12.7 (1/2")	
	Connecting method			Flare connection	
	Attached length of piping		m	Liquid line : 0.53 / Gas line : 0.40	
	Insulation for piping			Necessary (Both sides), independent	
	Refrigerant line (one way) length		m	Max. 25	
	Vertical height diff. between O.U. and I.U.		m	Max. 15 (Outdoor unit is higher) / Max. 15 (Outdoor unit is lower)	
Drain hose				Hose connectable (VP 16)	
Drain pump, max lift height			mm	—	
Recommended breaker size			A	16	
L.R.A. (Locked rotor ampere)			A	7.3 / 7.0 / 6.7 (220/ 230/ 240 V)	
Interconnecting wires		Size x Core number		1.5mm ² x 4 cores (Including earth cable) / Terminal block (Screw fixing type)	
IP number				IPX0	
Standard accessories				Mounting kit, Clean filter (Allergen clear filter x 1, Photocatalytic washable deodorizing filter x 1)	
Option parts				Interface kit (SC-BIKN-E)	
Note (1) The data are measured at the following conditions.					
The pipe length is 7.5m.					
Operation	Item	Indoor air temperature		Outdoor air temperature	
		DB	WB	DB	WB
	Cooling	27°C	19°C	35°C	24°C
	Heating	20°C	—	7°C	6°C
ISO5151-T1					
(2) This air-conditioner is manufactured and tested in conformity with the ISO.					
(3) Sound level indicates the value in an anechoic chamber. During operation these value are somewhat higher due to ambient conditions.					
(4) Select the breaker size according to the own national standard.					

2. EXTERIOR DIMENSIONS

(1) Indoor units

Models SRK20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S





RLA000Z054

(2) Outdoor units
Models SRC20ZM-S, 25ZM-S, 35ZM-S

- Notes
- (1) It must not be surrounded by walls on the four sides.
 - (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
 - (3) Where the unit is subject to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
 - (4) Leave 1m or more space above the unit.
 - (5) A wall in front of the blower outlet must not exceed the units height.
 - (6) The model name label is attached on the right side of the unit.

Symbol	Content
A	Service valve connection (gas side) $\phi 9.52$ (3/8") (Flare)
B	Service valve connection (liquid side) $\phi 6.35$ (1/4") (Flare)
C	Pipe / cable draw-out hole
D	Drain discharge hole $\phi 20 \times 2$ places
E	Anchor bolt hole M10 \times 4 places






Minimum installation space				
Examples of installation	I	II	III	IV
Dimensions				
L1	Open	280	280	180
L2	100	75	Open	Open
L3	100	80	80	80
L4	250	Open	250	Open

Unit:mm

Models SRC50ZM-S

- Notes
- (1) It must not be surrounded by walls on the four sides.
 - (2) The unit must be fixed with anchor bolts. An anchor bolt must not protrude more than 15mm.
 - (3) Where the unit is subject to strong winds, lay it in such a direction that the blower outlet faces perpendicularly to the dominant wind direction.
 - (4) Leave 1m or more space above the unit.
 - (5) A wall in front of the blower outlet must not exceed the units height.
 - (6) The model name label is attached on the right side of the unit.

Symbol	Content
A	Service valve connection (gas side) $\phi 12.7 (1/2")$ (Flare)
B	Service valve connection (liquid side) $\phi 6.35 (1/4")$ (Flare)
C	Pipe / cable draw-out hole
D	Drain discharge hole
E	Anchor bolt hole





Minimum installation space

Examples of installation	I	II	III	IV
Dimensions				
L1	Open	280	280	180
L2	100	75	Open	Open
L3	100	80	80	80
L4	250	Open	250	Open

Unit:mm

(3) Remote control

Unit : mm




3. ELECTRICAL WIRING

(1) Indoor units

Models SRK20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S


Item	Description
CNE-CNY	Connector
FMi	Fan motor
SMi	Flap motor
LMi ₂	Lower motor
HD	Humidity sensor
Thi	Room temp. sensor
Th23	Heat exch. sensor
DS	Diode stack
F	Fuse
T	Terminal block
Va	Varistor

Mark	Color
BK	Black
BL	Blue
RD	Red
WH	White
Y	Yellow
Y/G	Yellow/Green



(2) Outdoor units

Models SRC20ZM-S, 25ZM-S, 35ZM-S



Power cable, indoor-outdoor connecting wires

Model	MAX running current (A)	Power cable size (mm ²)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm ²)
20	8(ZMX) 9(ZM)	2.0	32	1.5mm ² x 3	1.5
25					
35					


- The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
- Switchgear of Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

Item	Description
CM	Compressor motor
CN20S	Connector
CNTH	
CNNEEV	
CNFAN	
EEEV	Electric expansion valve (coil)
FMo	Fan motor
L	Reactor
TB1	Terminal block
TH2	Heat exchanger sensor (outdoor unit)
TH3	Outdoor air temp. sensor
TH4	Discharge pipe temp. sensor
20S	Solenoid valve for 4 way valve

Mark	Color
BK	Black
OR	Orange
RD	Red
WH	White
Y	Yellow
Y / G	Yellow / Green

RWC000Z272

Models SRC50ZM-S



Mark	Color
BK	Black
BR	Brown
OR	Orange
RD	Red
WH	White
YE	Yellow
Y/G	Yellow / Green

Item	Description
CM	Compressor motor
CNEEV~CN20S	Connector
EEV	Electric expansion valve (coil)
FMo	Fan motor
R	Reactor
TB1,2	Terminal block
TH2	Heat exchanger sensor (outdoor unit)
TH3	Outdoor air temp.sensor
TH4	Discharge pipe temp.sensor
20S	Solenoid valve for 4 way valve

Model	MAX running current (A)	Power cable size (mm ²)	Power cable length (m)	indoor-outdoor wire size x number	Earth wire size (mm ²)
50	14	2.0	18	1.5mm ² x 3	1.5

- The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
- Switchgear of Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

RWC000Z269

4. NOISE LEVEL

Model SRK20ZM-S

(Indoor Unit)


Model	SRK20ZM-S	
Noise	Cooling	33 dB(A)
Level	Heating	36 dB(A)

Condition ISO-T1, JIS C 9612

●Mike position



× Cooling ○ — Heating




(Outdoor Unit)

Model	SRC20ZM-S	
Noise	Cooling	47 dB(A)
Level	Heating	46 dB(A)

●Mike position: at highest noise level in position as mentioned below
Distance from front side 1m

× Cooling ○ — Heating



Model SRK25ZM-S

(Indoor Unit)


Model	SRK25ZM-S	
Noise Level	Cooling	34 dB(A)
	Heating	39 dB(A)

Condition ISO-T1, JIS C 9612

●Mike position



× Cooling ○ — Heating




(Outdoor Unit)

Model	SRC25ZM-S	
Noise Level	Cooling	48 dB(A)
	Heating	49 dB(A)

●Mike position: at highest noise level in position as mentioned below
Distance from front side 1m

× Cooling ○ — Heating



Model SRK35ZM-S

(Indoor Unit)


Model	SRK35ZM-S	
Noise	Cooling	42 dB(A)
Level	Heating	43 dB(A)

Condition	ISO-T1, JIS C 9612
-----------	--------------------

●Mike position



× Cooling ○ — Heating




(Outdoor Unit)

Model	SRC35ZM-S	
Noise	Cooling	50 dB(A)
Level	Heating	51 dB(A)

●Mike position: at highest noise level in position as mentioned below
Distance from front side 1m

× Cooling ○ — Heating



Model SRK50ZM-S

(Indoor Unit)


Model	SRK50ZM-S	
Noise	Cooling	46 dB(A)
Level	Heating	45 dB(A)

Condition ISO-T1,JIS C 9612

●Mike position



× Cooling ○ — Heating




(Outdoor Unit)

Model	SRC50ZM-S	
Noise	Cooling	51 dB(A)
Level	Heating	53 dB(A)


●Mike position: at highest noise level in position as mentioned below
Distance from front side 1m

× Cooling ○ — Heating




5. PIPING SYSTEM


Models SRK20ZM-S, 25ZM-S



Model SRK35ZM-S



Model SRK50ZM-S



6. RANGE OF USAGE & LIMITATIONS


Item	Models	
	SRK20,25,35ZM-S	SRK50ZM-S
Indoor return air temperature (Upper, lower limits)	Cooling operation : Approximately 18 to 32°C D.B. Heating operation : Approximately 10 to 30°C D.B. (Refer to the selection chart)	
Outdoor air temperature (Upper, lower limits)	Cooling operation : Approximately -15 to 46°C D.B. Heating operation : Approximately -15 to 24°C D.B. (Refer to the selection chart)	
Refrigerant line (one way) length	Max. 15m	Max. 25m
Vertical height difference between outdoor unit and indoor unit	Max. 10m (Outdoor unit is higher)	Max. 15m (Outdoor unit is higher)
	Max. 10m (Outdoor unit is lower)	Max. 15m (Outdoor unit is lower)
Power source voltage	Rating $\pm 10\%$	
Voltage at starting	Min. 85% of rating	
Frequency of ON-OFF cycle	Max. 4 times/h (Inching prevention 10 minutes)	Max. 7 times/h (Inching prevention 5 minutes)
ON and OFF interval	Min. 3 minutes	

Selection chart

Correct the cooling and heating capacity in accordance with the conditions as follows. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown on specification × Correction factors as follows.

(1) Coefficient of cooling and heating capacity in relation to temperatures



(2) Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way piping length between the indoor and outdoor units.

Piping length [m]	7	10	15	20	25	30
Cooling	1.0	0.99	0.975	0.965	0.95	0.935
Heating	1.0	1.0	1.0	1.0	1.0	1.0

(3) Correction relative to frosting on outdoor heat exchanger during heating

In additions to the foregoing corrections (1), (2) the heating capacity needs to be adjusted also with respect to the frosting on the outdoor heat exchanger.

Air inlet temperature of outdoor unit in °CWB	-15	-10	-9	-7	-5	-3	-1	1	3	5 or more
Adjustment coefficient	0.95	0.95	0.94	0.93	0.91	0.88	0.86	0.87	0.92	1.00

How to obtain the cooling and heating capacity

Example : The net cooling capacity of the model SRK35ZM-S with the piping length of 15m, indoor wet-bulb temperature at 19.0°C and outdoor dry-bulb temperature 35°C is Net cooling capacity =

$$\begin{array}{ccccccc}
 \overbrace{3.5}^{\uparrow \text{SRK35ZM-S}} & \times & \overbrace{0.975}^{\uparrow \text{Length 15m}} & \times & \overbrace{1.0}^{\nearrow \text{Factor by air temperatures}} & \cong & 3.4 \text{ kW}
 \end{array}$$

7. CAPACITY TABLES

Model SRK20ZM-S

Cooling Mode

(kW)

Air flow	Outdoor air temp.	Indoor air temp													
		21°CDB		23°CDB		26°CDB		27°CDB		28°CDB		31°CDB		33°CDB	
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
Hi 7.8 (m³/min)	10	2.25	1.93	2.36	1.90	2.45	1.99	2.49	1.96	2.53	1.94	2.60	2.02	2.67	1.97
	12	2.21	1.91	2.32	1.88	2.41	1.97	2.45	1.95	2.50	1.93	2.58	2.01	2.65	1.96
	14	2.17	1.89	2.28	1.86	2.38	1.96	2.42	1.94	2.47	1.91	2.55	2.00	2.62	1.95
	16	2.13	1.87	2.24	1.85	2.34	1.94	2.39	1.92	2.43	1.90	2.52	1.99	2.59	1.94
	18	2.08	1.85	2.19	1.82	2.30	1.92	2.35	1.90	2.40	1.88	2.49	1.98	2.56	1.93
	20	2.04	1.83	2.15	1.81	2.26	1.91	2.31	1.89	2.36	1.87	2.45	1.97	2.53	1.92
	22	1.99	1.81	2.10	1.78	2.22	1.89	2.28	1.88	2.32	1.86	2.42	1.95	2.50	1.91
	24	1.94	1.78	2.05	1.76	2.18	1.88	2.24	1.86	2.28	1.85	2.38	1.94	2.47	1.90
	26	1.90	1.76	2.01	1.74	2.14	1.86	2.20	1.85	2.24	1.83	2.35	1.93	2.43	1.89
	28	1.85	1.74	1.96	1.72	2.09	1.84	2.15	1.83	2.20	1.82	2.31	1.92	2.40	1.88
	30	1.79	1.70	1.90	1.70	2.05	1.83	2.11	1.82	2.16	1.80	2.27	1.90	2.36	1.87
	32	1.74	1.65	1.85	1.68	2.00	1.81	2.07	1.80	2.12	1.79	2.23	1.89	2.32	1.86
	34	1.69	1.60	1.80	1.65	1.95	1.79	2.02	1.78	2.07	1.77	2.19	1.88	2.28	1.85
	35	1.66	1.58	1.77	1.64	1.93	1.78	2.00	1.78	2.05	1.76	2.17	1.87	2.26	1.84
	36	1.63	1.55	1.74	1.62	1.90	1.77	1.98	1.77	2.02	1.75	2.15	1.87	2.24	1.83
	38	1.58	1.50	1.68	1.60	1.85	1.75	1.93	1.75	1.98	1.74	2.11	1.85	2.20	1.82
	39	1.55	1.47	1.66	1.57	1.83	1.74	1.91	1.74	1.95	1.73	2.08	1.84	2.18	1.81

Heating Mode (HC)

(kW)

Air flow	outdoor air temp.	Indoor air temp				
		16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
Hi 9.8 (m³/min)	-15°CWB	1.66	1.63	1.59	1.55	1.52
	-10°CWB	1.88	1.85	1.82	1.78	1.74
	-5°CWB	2.04	2.01	1.97	1.94	1.91
	0°CWB	2.13	2.10	2.07	2.04	2.01
	5°CWB	2.72	2.69	2.67	2.62	2.58
	6°CWB	2.76	2.73	2.70	2.67	2.63
	10°CWB	2.94	2.91	2.89	2.85	2.82
	15°CWB	3.20	3.17	3.14	3.11	3.08
	20°CWB	3.43	3.41	3.39	3.35	3.32

Model SRK25ZM-S

Cooling Mode

(kW)

Air flow	Outdoor air temp.	Indoor air temp													
		21°CDB		23°CDB		26°CDB		27°CDB		28°CDB		31°CDB		33°CDB	
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
Hi 7.9 (m³/min)	10	2.82	2.23	2.95	2.19	3.06	2.27	3.11	2.24	3.16	2.21	3.26	2.28	3.34	2.21
	12	2.77	2.20	2.90	2.17	3.01	2.25	3.07	2.22	3.12	2.20	3.22	2.27	3.31	2.20
	14	2.71	2.17	2.85	2.14	2.97	2.23	3.03	2.21	3.08	2.18	3.18	2.25	3.28	2.19
	16	2.66	2.15	2.80	2.12	2.92	2.21	2.98	2.19	3.04	2.16	3.15	2.24	3.24	2.18
	18	2.60	2.12	2.74	2.09	2.88	2.19	2.94	2.17	2.99	2.14	3.11	2.22	3.20	2.17
	20	2.55	2.09	2.68	2.07	2.83	2.17	2.89	2.14	2.95	2.12	3.07	2.21	3.17	2.15
	22	2.49	2.06	2.63	2.04	2.78	2.14	2.84	2.12	2.90	2.10	3.02	2.20	3.13	2.14
	24	2.43	2.03	2.57	2.01	2.72	2.12	2.80	2.11	2.85	2.08	2.98	2.18	3.08	2.13
	26	2.37	2.00	2.51	1.98	2.67	2.10	2.74	2.09	2.80	2.07	2.93	2.16	3.04	2.11
	28	2.31	1.97	2.44	1.96	2.61	2.08	2.69	2.07	2.75	2.05	2.89	2.14	3.00	2.10
	30	2.24	1.94	2.38	1.92	2.56	2.05	2.64	2.05	2.70	2.03	2.84	2.13	2.95	2.08
	32	2.18	1.91	2.31	1.89	2.50	2.03	2.58	2.03	2.64	2.01	2.79	2.11	2.90	2.07
	34	2.11	1.88	2.25	1.87	2.44	2.01	2.53	2.00	2.59	1.99	2.74	2.09	2.85	2.05
	35	2.08	1.87	2.21	1.85	2.41	1.99	2.50	1.99	2.56	1.97	2.71	2.08	2.83	2.04
	36	2.04	1.85	2.18	1.84	2.38	1.98	2.47	1.98	2.53	1.96	2.69	2.08	2.80	2.03
	38	1.97	1.82	2.11	1.81	2.32	1.96	2.41	1.96	2.47	1.94	2.63	2.05	2.75	2.02
	39	1.94	1.80	2.07	1.79	2.28	1.94	2.38	1.94	2.44	1.93	2.61	2.05	2.72	2.01

Heating Mode (HC)

(kW)

Air flow	outdoor air temp.	indoor air temp				
		16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
Hi 10.6 (m³/min)	-15°CWB	1.97	1.93	1.88	1.84	1.80
	-10°CWB	2.23	2.19	2.16	2.10	2.06
	-5°CWB	2.41	2.38	2.33	2.30	2.27
	0°CWB	2.53	2.49	2.45	2.42	2.38
	5°CWB	3.22	3.19	3.17	3.10	3.06
	6°CWB	3.27	3.24	3.20	3.16	3.12
	10°CWB	3.48	3.45	3.42	3.38	3.34
	15°CWB	3.79	3.75	3.73	3.69	3.65
	20°CWB	4.07	4.04	4.02	3.97	3.94

Model SRK35ZM-S

Cooling Mode

(kW)

Air flow	Outdoor air temp.	Indoor air temp													
		21°CDB		23°CDB		26°CDB		27°CDB		28°CDB		31°CDB		33°CDB	
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB	
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
Hi 10.1 (m³/min)	10	3.94	3.00	4.13	2.95	4.28	3.04	4.35	3.00	4.43	2.97	4.56	3.04	4.68	2.94
	12	3.87	2.97	4.06	2.92	4.22	3.02	4.29	2.98	4.37	2.94	4.51	3.02	4.63	2.93
	14	3.80	2.93	3.99	2.88	4.16	2.99	4.24	2.96	4.31	2.91	4.46	3.00	4.59	2.91
	16	3.72	2.89	3.91	2.85	4.09	2.96	4.18	2.93	4.25	2.89	4.40	2.98	4.54	2.89
	18	3.65	2.85	3.84	2.81	4.03	2.93	4.11	2.90	4.19	2.87	4.35	2.96	4.49	2.88
	20	3.57	2.81	3.76	2.77	3.96	2.90	4.05	2.87	4.13	2.84	4.29	2.94	4.43	2.85
	22	3.49	2.77	3.68	2.73	3.89	2.86	3.98	2.83	4.06	2.80	4.23	2.92	4.38	2.84
	24	3.40	2.72	3.59	2.69	3.81	2.83	3.91	2.81	3.99	2.78	4.17	2.89	4.32	2.81
	26	3.32	2.68	3.51	2.65	3.74	2.80	3.84	2.78	3.92	2.75	4.11	2.86	4.26	2.80
	28	3.23	2.63	3.42	2.61	3.66	2.77	3.77	2.76	3.85	2.72	4.04	2.84	4.20	2.77
	30	3.14	2.59	3.33	2.57	3.58	2.74	3.70	2.72	3.78	2.70	3.98	2.82	4.13	2.75
	32	3.05	2.54	3.24	2.52	3.50	2.70	3.62	2.69	3.70	2.66	3.91	2.79	4.06	2.73
	34	2.95	2.50	3.14	2.48	3.41	2.66	3.54	2.66	3.62	2.63	3.84	2.77	4.00	2.69
	35	2.91	2.48	3.10	2.46	3.37	2.65	3.50	2.64	3.58	2.62	3.80	2.75	3.96	2.68
	36	2.86	2.46	3.05	2.44	3.33	2.63	3.46	2.63	3.54	2.60	3.76	2.72	3.92	2.67
	38	2.76	2.41	2.95	2.40	3.24	2.59	3.38	2.59	3.46	2.57	3.69	2.70	3.85	2.65
	39	2.71	2.39	2.90	2.37	3.20	2.57	3.33	2.58	3.42	2.56	3.65	2.69	3.81	2.64

Heating Mode (HC)

(kW)

Air flow	outdoor air temp.	indoor air temp				
		16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
Hi 12.8 (m³/min)	-15°CWB	2.46	2.41	2.35	2.30	2.25
	-10°CWB	2.79	2.74	2.70	2.63	2.58
	-5°CWB	3.02	2.97	2.91	2.88	2.83
	0°CWB	3.16	3.12	3.06	3.02	2.98
	5°CWB	4.03	3.98	3.96	3.88	3.83
	6°CWB	4.09	4.04	4.00	3.95	3.90
	10°CWB	4.35	4.31	4.28	4.22	4.18
	15°CWB	4.73	4.69	4.66	4.61	4.56
20°CWB	5.09	5.05	5.02	4.96	4.92	

Model SRK50ZM-S

Cooling Mode

(kW)

Air flow	Outdoor air temp.	Indoor air temp															
		21°CDB		23°CDB		26°CDB		27°CDB		28°CDB		31°CDB		33°CDB			
		14°CWB		16°CWB		18°CWB		19°CWB		20°CWB		22°CWB		24°CWB			
		TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC		
Hi 11.3 (m³/min)	10	5.63	4.09	5.90	4.02	6.11	4.12	6.22	4.05	6.32	3.99	6.51	4.05	6.69	3.92		
	12	5.53	4.03	5.80	3.97	6.03	4.07	6.14	4.01	6.25	3.96	6.44	4.02	6.62	3.89		
	14	5.43	3.98	5.70	3.91	5.94	4.03	6.05	3.98	6.16	3.92	6.37	4.00	6.55	3.86		
	16	5.32	3.92	5.59	3.86	5.85	3.98	5.96	3.93	6.08	3.88	6.29	3.96	6.48	3.84		
	18	5.21	3.85	5.48	3.80	5.75	3.94	5.88	3.90	5.99	3.84	6.21	3.93	6.41	3.81		
	20	5.10	3.79	5.37	3.74	5.65	3.89	5.78	3.85	5.90	3.80	6.13	3.90	6.33	3.78		
	22	4.98	3.73	5.25	3.68	5.55	3.84	5.69	3.81	5.80	3.76	6.05	3.86	6.25	3.75		
	24	4.86	3.67	5.14	3.62	5.45	3.79	5.59	3.76	5.71	3.72	5.96	3.83	6.17	3.72		
	26	4.74	3.60	5.01	3.56	5.34	3.74	5.49	3.71	5.61	3.67	5.87	3.79	6.08	3.69		
	28	4.61	3.54	4.89	3.50	5.23	3.69	5.39	3.67	5.50	3.63	5.78	3.76	5.99	3.66		
	30	4.49	3.46	4.76	3.43	5.11	3.64	5.28	3.62	5.40	3.58	5.68	3.72	5.90	3.62		
	32	4.35	3.40	4.63	3.37	5.00	3.58	5.17	3.57	5.29	3.54	5.58	3.68	5.81	3.59		
	34	4.22	3.33	4.49	3.31	4.88	3.52	5.06	3.52	5.18	3.49	5.48	3.64	5.71	3.55		
	35	4.15	3.29	4.42	3.27	4.82	3.49	5.00	3.49	5.12	3.45	5.43	3.62	5.66	3.53		
	36	4.08	3.26	4.35	3.24	4.76	3.47	4.94	3.46	5.06	3.43	5.37	3.60	5.61	3.50		
	38	3.94	3.19	4.21	3.18	4.63	3.42	4.82	3.42	4.94	3.39	5.27	3.54	5.50	3.47		
	39	3.87	3.15	4.14	3.14	4.57	3.39	4.76	3.39	4.88	3.36	5.21	3.52	5.45	3.45		

Heating Mode (HC)

(kW)

Air flow	outdoor air temp.	indoor air temp				
		16°CDB	18°CDB	20°CDB	22°CDB	24°CDB
Hi 13.5 (m ³ /min)	-15°CWB	3.57	3.49	3.41	3.34	3.26
	-10°CWB	4.04	3.97	3.91	3.81	3.73
	-5°CWB	4.37	4.31	4.22	4.18	4.11
	0°CWB	4.59	4.52	4.44	4.39	4.32
	5°CWB	5.84	5.77	5.74	5.63	5.55
	6°CWB	5.94	5.87	5.80	5.73	5.66
	10°CWB	6.31	6.25	6.21	6.12	6.06
	15°CWB	6.86	6.80	6.76	6.68	6.62
	20°CWB	7.38	7.32	7.28	7.20	7.14

Note(1) These data show average statuses.

Depending on the system control, there may be ranges where the operation is not conducted continuously.

These data show the case where the operation frequency of a compressor is fixed.

(2) Capacities are based on the following conditions.

Corresponding refrigerant piping length :7m

Level difference of Zero.

(3) Symbols are as follows.

TC : Total cooling capacity (kW)

SHC : Sensible heat capacity (kW)

HC : Heating capacity (kW)

8. APPLICATION DATA

(1) Installation of indoor unit

Models SRK20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S

RLA012A020

- This installation manual illustrates the method of installing an indoor unit.
- For electrical wiring work, please see instructions set out on the backside.
- For outdoor unit installation and refrigerant piping, please refer to page 27.

- A wired remote control unit is supplied separately as an optional part.
- When installing the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

SAFETY PRECAUTIONS

- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, gloves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:

	Never do it under any circumstances.
	Always do it according to the instruction.

CAUTION

Both mentions the important items to protect your health and safety so strictly follow them by any means.

Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **WARNING** and **CAUTION**.
- **WARNING** Wrong installation would cause serious consequences such as injuries or death.
- **CAUTION** Wrong installation might cause serious consequences depending on circumstances.

WARNING

- **Installation must be carried out by the qualified installer.**
If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except by the qualified installer.
- **Install the system in full accordance with the installation manual.**
Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire.
- **Be sure to use only for household and residence.**
If this appliance is installed in interior environment such as machine shop and etc., it can cause malfunction.
- **Use the original accessories and the specified components for installation.**
If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury.
- **Install the unit in a location with good support.**
Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury.
- **Ventilate the working area well in the event of refrigerant leakage during installation.**
If the refrigerant comes into contact with naked flames, poisonous gas is produced.
- **When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149).**
If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident.
- **After completed installation, check that no refrigerant leaks from the system.**
If refrigerant leaks into the room and comes into contact with an oven or other hot surface, poisonous gas is produced.
- **Use the prescribed pipes, flare nuts and tools for R410A.**
Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit.

- **Do not put the drainage pipe directly into drainage channels where poisonous gases such as sulphide gas can occur.**
Poisonous gases will flow into the room through drainage pipe and seriously affect the user's health and safety. This can also cause the corrosion of the indoor unit and a resultant unit failure or refrigerant leak.
- **Ensure that no air enters in the refrigerant circuit when the unit is installed and removed.**
If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury.

WARNING

- **Do not vent R410A into the atmosphere : R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with Global Warming Potential (GWP)=1975.**
The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.
- **Do not run the unit with removed panels or protections.**
Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks.

CAUTION

- **Carry out the electrical work for ground lead with care.**
Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.
- **Use the circuit breaker of correct capacity. Circuit breaker should be the one that disconnect all poles under over current.**
Using the incorrect one could cause the system failure and fire.
- **Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations.**
The isolator should be locked in OFF state in accordance with EN60204-1.
- **Be sure to install indoor unit properly according to the installation manual in order to run off the drainage smoothly.**
Improper installation of indoor unit can cause dropping water into the room and damaging personal property.
- **Install the drainage pipe to run off drainage securely according to the installation manual.**
Incorrect installation of the drainage pipe can cause dropping water into the room and damaging personal property.
- **Be sure to install the drainage pipe with descending slope of 1/100 or more, and not to make traps and air-bleedings.**
Check if the drainage runs off securely during commissioning and ensure the space for inspection and maintenance.
- **Secure a space for the installation, inspection and maintenance**
Insufficient space can result in accident such as personal injury due to serious accidents.
- **Do not install the unit in the locations listed below.**
 - Locations where carbon fiber, metal powder or any powder is floating.
 - Locations where any substances that can catch the unit such as sulphide gas, chlorine gas, acid and alkaline can occur.
 - Vehicles and ships.
 - Locations where cosmetic or special sprays are often used.
 - Locations with direct exposure of oil mist and steam such as kitchen and machine plant.
 - Locations where any machines which generate high frequency harmonics are used.
 - Locations with salty atmospheres such as coastlines.
 - Locations with heavy snow (if installed, be sure to provide base flame and snow hood mentioned in the manual).
 - Locations where the unit is exposed to chimney smoke.
 - Locations at high altitude (more than 1000m high).
 - Locations with ammoniac atmospheres.
 - Locations where heat radiation from other heat source can affect the unit.
 - Locations without good air circulation.
 - Locations with any obstacles which can prevent inlet and outlet air of the unit.
 - Locations where short circuit of air can occur (in case of multiple units installation).
 - Locations where strong air blows against the air outlet of outdoor unit.
 - Locations where something located above the unit could fall.
 - Locations where remarkable decrease in performance, corrosion and damage of components, malfunction and fire.
- **Do not install the indoor unit in the locations listed below (be sure to install the indoor unit according to the installation manual for each model because each indoor unit has each limitation).**
 - Locations with any obstacles which can prevent inlet and outlet air of the unit.
 - Locations where vibration can be amplified due to insufficient strength of structure.
 - Locations where the infrared receiver is exposed to the direct sunlight or the strong light beam (in case of the infrared specification unit).
 - Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).
 - Locations where drainage cannot run off safely.
 - It can affect performance or function and etc.
- **Do not install the unit near the location where leakage of combustible gases can occur**

WARNING

- **Do not perform any change of protective device itself or its setup condition.**
The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.
- **Do not touch any parts with wet hands.**
Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.
- **Do not touch any buttons with wet hands.**
It can cause electric shocks.
- **Do not touch any refrigerant pipes with your hands when the system is in operation.**
During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.

BEFORE INSTALLATION

- Before installation check that the power supply matches the air conditioner.

Standard accessories (Installation kit)	
Accessories for indoor unit	
① Installation board (Attached to the rear of the indoor unit)	1
② Wireless remote control	1
③ Remote control holder	1
④ Tapping screws (for installation board ø4 X 25mm)	5
⑤ Wood screws (for remote control holder ø3.5 X 16mm)	2
⑥ Battery [R03 (AAA, Micro) 1.5V]	2
⑦ Air-cleaning filters	2
⑧ Filter holders (Attached to the front panel of indoor unit)	2
⑨ Insulation (#486 50 x 100 (3))	1

Option parts	
① Sealing plate	1
② Sleeve	1
③ Inclination plate	1
④ Putty	1
⑤ Drain hose (extension hose)	1
⑥ Piping cover (for insulation of connection piping)	1

Necessary tools for the installation work	
1 Plus headed driver	
2 Knife	
3 Saw	
4 Tape measure	
5 Hammer	
6 Spanner wrench	
7 Torque wrench (14.0 - 61.0N·m (1.4 - 6.1kgf·m))	
8 Hole core drill (65mm in diameter)	
9 Wrench key (Hexagon) [4m/m]	
10 Flaring tool set (Designed specifically for R410A)	
11 Gas leak detector (Designed specifically for R410A)	
12 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)	
13 Pipe bender	

SELECTION OF INSTALLATION LOCATION

(Install at location that meets the following conditions, after getting approval from the customer.)

Indoor unit

- Where there is no obstructions to the air flow and where the cooled and heated air can be evenly distributed.
- A solid place where the unit or the wall will not vibrate.
- A place where there will be enough space for servicing. (Where space mentioned below can be secured)
- Where wiring and the piping work will be easy to conduct.
- The place where receiving part is not exposed to the direct rays of the sun or the strong rays of the street lighting.
- A place where it can be easily drained.
- A place separated at least 1m away from the television or the radio. (To prevent interference to images and sounds.)
- Places where this unit is not affected by the high frequency equipment or electric equipment.
- Places where there is no electric equipment or household under the installing unit.


Wireless remote control

- A place where the air conditioner can be received the signal surely during operating the wireless remote control.
- Places where there is no affected by the TV and radio etc.
- Do not place where exposed to direct sunlight or near heat devices such as a stove.

INSTALLATION OF INDOOR UNIT

Installation of installation board


Look for the inside wall structures (intermediates support or pillar and firmly install the unit after level surface has been checked.)



- Adjustment of the installation board in the horizontal direction is to be conducted with four screws in a temporary tightened state.
- Adjust so the board will be level by turning the board with the standard hole as the center.

Drilling of holes and fixture of sleeve (Option parts)

When drilling the wall that contains a metal lath, wire lath or metal plate, be sure to use pipe hole sleeve sold separately.



Installing the support of piping

In case of piping in the right rear direction

Shaping of pipings


Taping of the exterior

Pipings

Drain hose

- Hold the bottom of the piping and fix direction with the flaring tool and shaping it.
- Always tape the wiring with the piping.

Sufficient care must be taken not to damage the panel when connecting pipes.



CAUTION


Completely seal the hole on the wall with putty. Otherwise, furniture, or other, may be wetted by leaked water or dewing.

② Wireless remote control

③ Remote control holder


④ Wood screws

Relation between setting plate and indoor unit




(Unit : mm)

Drain hose changing procedures




(Unit : mm)

Fixing of indoor unit




Installation Steps

- ① Pass the pipe through the hole in the wall, and hook the upper part of the indoor unit to the installation board.
- ② Gently push the lower part to secure the unit.








- How to remove the indoor unit from the installation board**
- ① Push up at the marked portion of the indoor unit base lower latch, and slightly pull it toward you. (both right and left hand sides) (The indoor unit base lower latch can be removed from the installation board)
 - ② Push up the indoor unit upward. So the indoor unit will be removed from the installation board.




Drainage

- Arrange the drain hose in a downward angle.
 - Avoid the following drain piping.

⚠ CAUTION Go through all installation steps and check if the drainage is all right. Otherwise water leak may occur.

 <p>Higher than specified</p>	 <p>The drain hose tip is in water.</p>	 <p>Wavy</p>	 <p>The gap to the ground is 5 cm or less.</p>	 <p>Odor from the gutter</p>
--	--	---	---	---

 - Pour water is the drain pan located under the heat exchanger, and ensure that the water is discharged outdoor.
 - When the expanded drain hose is indoor, securely insulate it with a heat insulator available in the market.



Since this air conditioner has been designed to collect dew drops on the rear surface to the drain pan, do not attach the power cord above the gutter.

CONNECTION OF REFRIGERANT PIPINGS

Preparation Keep the openings of the pipes covered with tapes etc. to prevent dust, sand, etc. from entering them.

Indoor



press
ve
sides)



⚠ CAUTION
Do not apply refrigerating machine oil to the flared surface.

Dimension A
Liquid side $\phi 6.35$: 9.1 (mm)
Gas side $\phi 9.52$: 13.2 (mm)
 $\phi 12.7$: 16.6 (mm)

- ☐ Remove the flared nuts. (on both liquid and gas sides)
- ☐ Install the removed flared nuts to the pipes to be connected, then flared the pipes.

Flaring work


Copper pipe diameter	Measurement B (mm)		
	Clutch type flare tool for R410A	Conventional R202 flare tool	Wing nut type Clutch type
ø6.35	0.0 - 0.5	1.5 - 2.0	
ø9.52	0.0 - 0.5	1.0 - 1.5	1.5 - 2.0
ø12.7	0.0 - 0.5	1.0 - 1.5	2.0 - 2.5

Use a flare tool designed for R410A or a conventional flare tool.

Measurement B (position from the flange body) will vary depending on the type of flare tool used.

If a conventional flare tool is used, please use a copper pipe gauge or a similar instrument to check that position so that you can keep measurement B to a correct value.

Use a flare tool designed for R410A or a conventional flare tool. Please note that measurement B (protrusion from the flaring block) will vary depending on the type of a flare tool in use.



Connection




Indoor

Liquid side
Gas side
(Do not turn)


- ① Connect the pipes on both liquid and gas sides.
② Tighten the nuts to the following torque.
- | |
|---|
| Liquid side (ø6.35) : 14.0 - 18.0 N·m (1.4 - 1.8 kgf·m) |
| Gas side (ø9.52) : 34.0 - 42.0 N·m (3.4 - 4.2 kgf·m) |
| Gas side (ø12.7) : 49.0 - 61.0 N·m (4.9 - 6.1 kgf·m) |


Insulation of the connection portion




Cover the coupling with insulator and then cover it with tapes.

Use an attached insulation pad for heat insulation.



- 
- Position it so that the silt area faces upward.
- Cover the indoor unit's flare-connected joints, after they are checked for a gas leak, with an indoor unit heat insulating material and then wrap them with a tape with an attached insulation pad placed over the heat insulating material's silt area.


Finishing work and fixing



Cover the exterior portion with outer tape and shape the piping so it will match the contours of the route that the piping to take. Also fix the wiring and pipings to the wall with staples.


Open/close and detachment/attachment of the air inlet panel

- To open, pull the panel at both ends of lower part and release latches, then pull up the panel until you feel resistance.
(The panel stops at approx. 60° open position)
- To close, hold the panel at both ends of lower part to lower downward and push it slightly until the latch works.
- To remove, pull up the panel to the position shown in right illustration and pull it toward you.
- To install, insert the panel arm into the slot on the front panel from the position shown in right illustration, hold the panel at both ends of lower part, lower it downward slowly, then push it slightly until the latch works.



How to remove and fit the front panel

- ① Removing
- ① Remove the air inlet panel.
- ② Remove the 2 set screws.
- ③ Remove the 3 latches in the upper section.
- ④ Move the lower part of the panel forward and push upwards to remove.
- ⑤ Fitting
- ① Do remove the air filter.
- ② Cover the body with the front panel.
- ③ Fit the 3 latches in the upper section.
- ④ Tighten the 2 set screws.
- ⑤ Fit the air filter.
- ⑥ Fit the air inlet panel.



ELECTRICAL WIRING WORK

Preparation of indoor unit

Mounting of connecting wires

- ① Remove the lid.
- ② Remove the terminal cover.
- ③ Connect the connecting wire securely to the terminal block.
- ④ Connect the connection wire securely to the terminal block. If the wire is not affixed completely, contact will be poor, and it is dangerous as the terminal block may heat up and catch fire.
- ⑤ Take care not to confuse the terminal numbers for indoor and outdoor connections.
- ⑥ Fix the connecting wire by wiring clamp.
- ⑦ Attach the terminal cover.


CAUTION

In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.

Use cables for interconnection wiring to avoid loosening of the wires.
CENELEC code for cables Required field cables.

H5RN4G1.5 (example) or 245EC57
H Harmonized cable type
05 300/500 volts
R Natural-and/or synth. rubber wire insulation
N Polythiophene rubber conductors insulation
R Stranded core
4x5 Number of conductors
G One conductor of the cable is the earth conductor (yellow/green)
1.5 Section of copper wire (mm²)


• Earth wire shall be Yellow/Green (YG) in color and longer than other AC wires for safety reason.



The screws of the lid and the terminal cover are tightened securely.

Installing the air-cleaning filters


1. Open the air inlet panel and remove the air filters.
2. Install the air-cleaning filter in the filter holders, and then install the filter holders in the air conditioner.
3. Install the air filters and close the inlet panel.



INSTALLATION OF WIRELESS REMOTE CONTROL

Mounting method of battery


- Uncover the wireless remote control, and mount the batteries [R03 (AAA, Micro), x2 pieces] in the body regularly. (Fit the poles with the indication marks, ⊕ & ⊖ without fail)



CAUTION
Do not use new and old batteries together.

Fixing to pillar or wall

- Conventionally, operate the wireless remote control by holding in your hand.
- Avoid installing it on a clay wall etc.



HOW TO RELOCATE OR DISPOSE OF THE UNIT

- In order to protect the environment, be sure to pump down (recovery of refrigerant).
- Pump down is the method of recovering refrigerant from the indoor unit to the outdoor unit when the pipes are removed from the unit.

<How to pump down>

- ① Connect change hose to check joint of outdoor unit.
- ② Liquid side : Close the liquid valve with hexagon wrench key.
Gas side : Fully open the gas valve.
Carry out cooling operation. (If indoor temperature is low, operate forced cooling operation.)
- ③ After low pressure gauge becomes 0.01MPa, stop cooling operation and close the gas valve.




- Forced cooling operation
Turn on a power supply again after a while after turn off a power supply.
Then press continually the ON/OFF button 5 seconds or more.

INSTALLING TWO AIR CONDITIONERS IN THE SAME ROOM

When two air conditioners are installed in the same room, use this setting when the two air conditioners are not operated with one wireless remote control. Set the wireless remote control and indoor unit.


Setting an indoor unit

- ① Turn off the power supply, and turn it on after 1 minute.
- ② Point the wireless remote control that was set according to the procedure described on the left side at the indoor unit and send a signal by pressing the AC L switch on the wireless remote control.
Since the signal is sent in about 6 seconds after the AC L switch is pressed, point the wireless remote control at the indoor unit for some time.
- ③ Check that the reception buzzer sound "pp" is emitted from the indoor unit.
At completion of the setting, the indoor unit emits a buzzer sound "pp". (If no reception tone is emitted, start the setting from the beginning again.)



Setting the wireless remote control


- ① Pull out the cover and take out batteries.
- ② Disconnect the switching line next to the battery with wire cutters.



- ③ Insert batteries. Close the cover.

CONCERNING TERMINAL CONNECTION FOR AN INTERFACE

- ① Remove the front panel and lid of control.
- ② Remove the control.
- ③ There is a terminal (respectively marked with CNS) for the indoor control board. In connecting an interface, connect to the respective terminal securely with the connection harness supplied with an optional "Interface connection kit SC-BIKH-E" and fasten the connection harness onto the indoor control box with the clamp supplied with the kit.
For more details, please refer to the user's manual of your "Interface connection kit SC-BIKH-E".



INSTALLATION TEST CHECK POINTS

After installation

- ☐ The power supply voltage is correct as the rating.
- ☐ No gas leaks from the joints of the service valve.
- ☐ Power cables and crossover wires are securely fixed to the terminal board.
- ☐ The screw of the lid and the terminal cover are tightened securely.

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. At the same time, explain to the customer how to use the unit and how to take care of the unit following the user's manual.

Test run

- ☐ Air conditioning operation is normal.
- ☐ The wireless remote control is normal.
- ☐ No abnormal noise.
- ☐ Operation of the unit has been explained to the customer. (Three-minutes restart preventive timer)
- ☐ Water drains smoothly.
- ☐ When the air conditioner is restarted or when changing the operation, the unit will not start operating for approximately 3 minutes. This is to protect the unit and it is not a malfunction.
- ☐ Protective functions are not working.

(2) Installation of outdoor unit

Models SRC20ZM-S, 25ZM-S, 35ZM-S, 50ZM-S

- This installation manual deals with outdoor units and general installation specifications only. For indoor units, refer to page 23.
- When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation (piping length, height differences between indoor and outdoor units, power supply voltage and etc.) and installation spaces.

SAFETY PRECAUTIONS

- Read the "SAFETY PRECAUTIONS" carefully first of all and strictly follow it during the installation work in order to protect yourself.
- The precautionary items mentioned below are distinguished into two levels, **⚠ WARNING** and **⚠ CAUTION**.
⚠ WARNING : Wrong installation would cause serious consequences such as injuries or death.
⚠ CAUTION : Wrong installation might cause serious consequences depending on circumstances.
 Both mentions the important items to protect your health and safety so strictly follow them by any means.
- Be sure to confirm no anomaly on the equipment by commissioning after completed installation and explain the operating methods as well as the maintenance methods of this equipment to the user according to the owner's manual.

- Keep the installation manual together with owner's manual at a place where any user can read at any time. Moreover if necessary, ask to hand them to a new user.
- For installing qualified personnel, take precautions in respect to themselves by using suitable protective clothing, groves, etc., and then perform the installation works.
- Please pay attention not to fall down the tools, etc. when installing the unit at the high position.
- If unusual noise can be heard during operation, consult the dealer.
- The meanings of "Marks" used here are shown as follows:

	Never do it under any circumstances.
	Always do it according to the instruction.

⚠ WARNING

<p>ⓘ</p> <ul style="list-style-type: none"> • Installation must be carried out by the qualified installer. If you install the system by yourself, it may cause serious trouble such as water leaks, electric shocks, fire and personal injury, as a result of a system malfunction. Do not carry out the installation and maintenance work except the by qualified installer. • Install the system in full accordance with the installation manual. Incorrect installation may cause bursts, personal injury, water leaks, electric shocks and fire. • Be sure to use only for household and residence. If this appliance is installed in interior environment such as machine shop and etc., it can cause malfunction. • When installing in small rooms, take prevention measures not to exceed the density limit of refrigerant in the event of leakage, referred by the formula (accordance with ISO5149). If the density of refrigerant exceeds the limit, please consult the dealer and install the ventilation system, otherwise lack of oxygen can occur, which can cause serious accident. • Use the original accessories and the specified components for installation. If parts other than those prescribed by us are used, it may cause water leaks, electric shocks, fire and personal injury. • Install the unit in a location with good support. Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury. • Ensure the unit is stable when installed, so that it can withstand earthquakes and strong winds. Unsuitable installation locations can cause the unit to fall and cause material damage and personal injury. 	<p>ⓘ</p> <ul style="list-style-type: none"> • Ventilate the working area well in the event of refrigerant leakage during installation. If the refrigerant comes into contact with naked flames, poisonous gas is produced. • Use the prescribed pipes, flare nuts and tools for R410A. Using existing parts (for R22 or R407C) can cause the unit failure and serious accidents due to burst of the refrigerant circuit. • Tighten the flare nut by torque wrench with specified method. If the flare nut were tightened with excess torque, this may cause burst and refrigerant leakage after a long period. • Do not open the service valves for liquid line and gas line until completed refrigerant piping work, air tightness test and evacuation. If the compressor is operated in state of opening service valves before completed connection of refrigerant piping work, air can be sucked into refrigerant circuit, which can cause burst or personal injury due to anomalously high pressure in the refrigerant. • The electrical installation must be carried out by the qualified electrician in accordance with "the norm for electrical work" and "national wiring regulation", and the system must be connected to the dedicated circuit. Power supply with insufficient capacity and incorrect function done by improper work can cause electric shocks and fire. • Be sure to shut off the power before starting electrical work. Failure to shut off the power can cause electric shocks, unit failure or incorrect function of equipment. • Be sure to use the cables conformed to safety standard and cable ampacity for power distribution work. Unconformable cables can cause electric leak, anomalous heat production or fire. • This appliance must be connected to main power supply by means of a 	<p>ⓘ</p> <ul style="list-style-type: none"> • circuit breaker or switch (fuse:16A) with a contact separation of at least 3mm. • Arrange the wiring in the control box so that it cannot be pushed up further into the box. Install the service panel correctly. Incorrect installation may result in overheating and fire. • Use the prescribed cables for electrical connection, tighten the cables securely in terminal block and relieve the cables correctly to prevent overloading the terminal blocks. Loose connections or cable mountings can cause anomalous heat production or fire. • Be sure to fix up the service panels. Incorrect fixing can cause electric shocks or fire due to intrusion of dust or water. • Be sure to switch off the power supply in the event of installation, inspection or servicing. If the power supply is not shut off, there is a risk of electric shocks, unit failure or personal injury due to the unexpected start of fan. • Stop the compressor before removing the pipe after shutting the service valve on pump down work. If the pipe is removed when the compressor is in operation with the service valve open, air would be mixed in the refrigeration circuit and it could cause explosion and injuries due to abnormal high pressure in the cooling cycle. • Only use prescribed optional parts. The installation must be carried out by the qualified installer. If you install the system by yourself, it can cause serious trouble such as water leaks, electric shocks, fire. • Be sure to wear protective goggles and gloves while at work. • Earth leakage breaker must be installed. If the earth leakage breaker is not installed, it can cause electric shocks.
<p>⊘</p> <ul style="list-style-type: none"> • Ensure that no air enters in the refrigerant circuit when the unit is installed and removed. If air enters in the refrigerant circuit, the pressure in the refrigerant circuit becomes too high, which can cause burst and personal injury. • Do not processing, splice the power cord, or share a socket with other power plugs. This may cause fire or electric shock due to defecting contact, defecting insulation and over-current etc. 	<p>⊘</p> <ul style="list-style-type: none"> • Do not bundling, winding or processing for the power cord. Or, do not deforming the power plug due to tread it. This may cause fire or heating. • Do not run the unit with removed panels or protections. Touching rotating equipments, hot surfaces or high voltage parts can cause personal injury due to entrapment, burn or electric shocks. 	<p>⊘</p> <ul style="list-style-type: none"> • Do not perform any change of protective device itself or its setup condition. The forced operation by short-circuiting protective device of pressure switch and temperature controller or the use of non specified component can cause fire or burst.

RWC012A037
Model SRC20-25-35-50 DXC09-12-18
R410A REFRIGERANT USED

CAUTION

	<ul style="list-style-type: none">• Carry out the electrical work for ground lead with care. Do not connect the ground lead to the gas line, water line, lightning conductor or telephone line's ground lead. Incorrect grounding can cause unit faults such as electric shocks due to short-circuiting.
	<ul style="list-style-type: none">• Use the circuit breaker for all pole correct capacity. Circuit breaker should be the one that disconnect all poles under over current. Using the incorrect circuit breaker, it can cause the unit malfunction and fire.• Install isolator or disconnect switch on the power supply wiring in accordance with the local codes and regulations. The isolator should be locked in OFF state in accordance with EN60204-1.• After maintenance, all wiring, wiring ties and the like, should be returned to their original state and wiring route, and the necessary clearance from all metal parts should be secured.• Secure a space for installation, inspection and maintenance specified in the manual. Insufficient space can result in accident such as personal injury due to falling from the installation place.
	<ul style="list-style-type: none">• Do not install the unit in the locations listed below.<ul style="list-style-type: none">• Locations where carbon fiber, metal powder or any powder is floating.• Locations where any substances that can affect the unit such as sulphide gas, chloride gas, acid and alkaline can occur.• Vehicles and ships.• Locations where cosmetic or special sprays are often used.• Locations with direct exposure of oil mist and steam such as kitchen and machine plant.• Locations where any machines which generate high frequency harmonics are used.• Locations with salty atmospheres such as coastlines.• Locations with heavy snow (If installed, be sure to provide base flame and snow hood mentioned in the manual).• Locations where the unit is exposed to chimney smoke.• Locations at high altitude (more than 1000m high).• Locations with armonic atmospheres.• Locations where heat radiation from other heat source can affect the unit.• Locations without good air circulation.• Locations with any obstacles which can prevent inlet and outlet air of the unit.• Locations where short circuit of air can occur (in case of multiple units installation).• Locations where strong air blows against the air outlet of outdoor unit.• Locations where something located above the unit could fall. It can cause remarkable decrease in performance, corrosion and damage of components, malfunction and fire.• Do not install the unit near the location where leakage of combustible gases can occur. If leaked gases accumulate around the unit, it can cause fire.• Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled. Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.• Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics. Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
	<ul style="list-style-type: none">• Take care when carrying the unit by hand. If the unit weights more than 20kg, it must be carried by two or more persons. Do not carry by the plastic straps, always use the carry handle when carrying the unit by hand. Use gloves to minimize the risk of cuts by the aluminum fins.• Dispose of any packing materials correctly. Any remaining packing materials can cause personal injury as it contains nails and wood. And to avoid danger of suffocation, be sure to keep the plastic wrapper away from children and to dispose after tear it up.• Be sure to insulate the refrigerant pipes so as not to condense the ambient air moisture on them. Insufficient insulation can cause condensation, which can lead to moisture damage on the ceiling, floor, furniture and any other valuables.• Do not install the outdoor unit in the locations listed below.<ul style="list-style-type: none">• Locations where discharged hot air or operating sound of the outdoor unit can bother neighborhood.• Locations where outlet air of the outdoor unit blows directly to an animal or plants. The outlet air can affect adversely to the plant etc.• Locations where vibration can be amplified and transmitted due to insufficient strength of structure.• Locations where vibration and operation sound generated by the outdoor unit can affect seriously (on the wall or at the place near bed room).• Locations where an equipment affected by high harmonics is placed (TV set or radio receiver is placed within 1m).• Locations where drainage cannot run off safely.• Locations where surrounding environment and cause a claim.• Do not install the unit near the location where leakage of combustible gases can occur. If leaked gases accumulate around the unit, it can cause fire.• Do not install the unit where corrosive gas (such as sulfuric acid gas etc.) or combustible gas (such as thinner and petroleum gases) can accumulate or collect, or where volatile combustible substances are handled. Corrosive gas can cause corrosion of heat exchanger, breakage of plastic parts and etc. And combustible gas can cause fire.• Do not install nor use the system close to the equipment that generates electromagnetic fields or high frequency harmonics. Equipment such as inverters, standby generators, medical high frequency equipments and telecommunication equipments can affect the system, and cause malfunctions and breakdowns. The system can also affect medical equipment and telecommunication equipment, and obstruct its function or cause jamming.
	<ul style="list-style-type: none">• When perform the air conditioner operation (cooling or drying operation) in which ventilator is installed in the room. In this case, using the air conditioner in parallel with the ventilator, there is the possibility that drain water may backflow in accordance with the room lapse into the negative pressure status. Therefore, set up the opening port such as incorporate the air into the room that may appropriate to ventilation (For example: Open the door a little). In addition, just as above, so set up the opening port if the room lapse into negative pressure status due to register of the wind for the high rise apartment etc.
	<ul style="list-style-type: none">• Do not install the outdoor unit in a location where insects and small animals can inhabit. Insects and small animals can enter the electric parts and cause damage or fire. Instruct the user to keep the surroundings clean.• Do not use the base flame for outdoor unit which is corroded or damaged due to long periods of operation. Using an old and damage base flame can cause the unit falling down and cause personal injury.• Do not use any materials other than a fuse with the correct rating in the location where fuses are to be used. Connecting the circuit with copper wire or other metal thread can cause unit failure and fire.• Do not touch any buttons with wet hands. It can cause electric shocks.• Do not touch any refrigerant pipes with your hands when the system is in operation. During operation the refrigerant pipes become extremely hot or extremely cold depending the operating condition, and it can cause burn injury or frost injury.• Do not touch the suction or aluminum fin on the outdoor unit. This may cause injury.• Do not put anything on the outdoor unit and operating unit. This may cause damage the objects or injury due to falling to the object.• Do not use the unit for special purposes such as storing foods, cooling precision instruments and preservation of animals, plants or art.• Do not clean up the unit with water.

Check before installation work

- Model name and power source
- Refrigerant piping length
- Piping, wiring and miscellaneous small parts
- Indoor unit installation manual

Accessories for outdoor unit		Q'ty
Grommet	SRC20~35	
① Heat pump type only)	Model DXC09, 12	1
	Model SRC50/DXC18	4

② Drain elbow (Heat pump type only)		Q'ty
Option parts		
④ Sealing plate		1
⑤ Sleeve		1
⑥ Inclination plate		1
③ Putty		1
⑥ Drain hose (extension hose)		1
⑦ Piping cover (for insulation of connection piping)		1

Necessary tools for the installation work		
1 Plus headed driver		9 Wrench key (Hexagon) [4m/m]
2 Knife		10 Vacuum pump
3 Saw		11 Vacuum pump adapter (Anti-reverse flow type) (Designed specifically for R410A)
4 Tape measure		12 Gauge manifold (Designed specifically for R410A)
5 Hammer		13 Charge hose (Designed specifically for R410A)
6 Spanner wrench		14 Flaring tool set (Designed specifically for R410A)
7 Torque wrench [14.0~62.0N·m (1.4~6.2kgf·m)]		15 Gas leak detector (Designed specifically for R410A)
8 Hole core drill (65mm in diameter)		16 Gauge for projection adjustment (Used when flare is made by using conventional flare tool)

Notabilia as a unit designed for R410A


- Do not use any refrigerant other than R410A. R410A will rise to pressure about 1.6 times higher than that of a conventional refrigerant.
- A cylinder containing R410A has a pink indication mark on the top.
- A unit designed for R410A has adopted a different size indoor unit service valve charge port and a different size check joint provided in the unit to prevent the charging of a wrong refrigerant by mistake. The processed dimension of the flared part of a refrigerant pipe and a flare nut's parallel side measurement have also been altered to raise strength against pressure.
- Accordingly, you are required to arrange dedicated R410A tools listed in the table on the left before installing or servicing this unit.
- Do not use a charge cylinder. The use of a charge cylinder will cause the refrigerant composition to change, which results in performance degradation.
- In charging refrigerant, always take it out from a cylinder in the liquid phase.
- All indoor units must be models designed exclusively for R410A. Check connectable indoor unit models in a catalog, etc. (A wrong indoor unit, if connected into the system, will impair proper system operation)

1. HAULAGE AND INSTALLATION (Take particular care in carrying in or moving the unit, and always perform such an operation with two or more persons.)

⚠ CAUTION When a unit is hoisted with slings for haulage, take into consideration the offset of its gravity center position. If not properly balanced, the unit can be thrown off-balance and fall.


1) Delivery

- Deliver the unit as close as possible to the installation site before removing it from the packaging.
- When you have to unpack the unit for a compelling reason before you haul it to the installation point, hoist the unit with nylon slings or ropes and protection pads so that you may not damage the unit.



2) Portage

- The right hand side of the unit as viewed from the front (diffuser side) is heavier. A person carrying the right hand side must take heed of this fact. A person carrying the left hand side must hold with his right hand the handle provided on the front panel of the unit and with his left hand the corner column section.




3) Selecting the installation location

Be careful of the following conditions and choose an installation place.

- Where air is not trapped.
- Where the installation fittings can be firmly installed.
- Where wind does not hinder the intake and outlet pipes.
- Out of the heat range of other heat sources.
- A place where stringent regulation of electric noises is applicable.
- Where it is safe for the drain water to be discharged.
- Where noise and hot air will not bother neighboring residents.
- Where snow will not accumulate.
- Where strong winds will not blow against the outlet pipe.
- A place where no TV set or radio receiver is placed within 1m.
- If electrical interference is caused, seek a place less likely to cause the problem (If operation is conducted when the outdoor air temperature is -5°C lower, the outdoor unit should be installed at a place where it is not influenced by natural wind.
- Where it is likely that the unit is subjected to strong winds, provide wind guards according to the following guidelines. Strong winds can cause performance degradation, an accidental stop due to a rise of high pressure and a broken fan.

4) Caution about selection of installation location

- (1) If the unit is installed in the area where the snow will accumulate, following measures are required.
The bottom plate of unit and intake, outlet may be blocked by snow.
- 2 Install the unit under or provide the roof on site.
higher than snow cover surface.



Since drain water generated by defrost control may freeze, following measures are required.
• Do not execute drain piping work by using a drain elbow and drain grommets (accessories).
[Refer to Drain piping work.]

- (2) If the unit can be affected by strong wind, following measures are required.
Strong wind can cause damage of fan (fan motor), or can cause performance degradation, or can trigger anomalous stop of the unit due to rising of high pressure.


- 1 Place the unit outlet side is turned to the wall.
- 2 Install so the direction of the air from the blowing outlet will be perpendicular to the direction of the wind.



5) Installation space

Model SRC20~50/DXC09~18				
Example installation	I	II	III	IV
Size	L1	280	280	180
	L2	100	75	Open
	L3	100	80	80
	L4	250	Open	250
				Open

The height of a wall is 1200mm or less.




- Walls surrounding the unit in the four sides are not acceptable.
- There must be a 1-meter or larger space in the above.
- When more than one unit are installed side by side, provide a 250mm or wider interval between them as a service space. In order to facilitate servicing of controllers, please provide a sufficient space between units so that their top plates can be removed easily.
- Where a danger of short-circuiting exists, install guide louvers.
- When more than one unit are installed, provide sufficient intake space consciously so that short-circuiting may not occur.
- Where piling snow can bury the outdoor unit, provide proper snow guards.


6) Installation

- ① Anchor bolt fixed position


Model SRC20~35/DXC09,12



Model SRC50/DXC18



- ② Notabilia for installation




- In installing the unit, fix the unit's legs with bolts specified on the above.
- The protrusion of an anchor bolt on the front side must be kept within 15mm.
- Securely install the unit so that it does not fall over during earthquakes or strong winds, etc.
- Refer to the above illustrations for information regarding concrete foundations.
- Install the unit in a level area. (With a gradient of 5mm or less.) Improper installation can result in a compressor failure, broken piping within the unit and abnormal noise generation.

2. REFRIGERANT PIPING WORK

1) Restrictions on unit installation and use

- Check the following points in light of the indoor unit specifications and the installation site.
- Observe the following restrictions on unit installation and use. Improper installation can result in a compressor failure or performance degradation.
- Additional refrigerant charge is not required at all (Model SRC20~35DXC09.12).

Restrictions	Dimensional restrictions		Marks appearing in the drawing on the right
	Model SRC20~35DXC09.12	Model SRC50DXC18	
Main pipe length	15m or less	25m or less	L
Elevation difference between indoor and outdoor units	When the outdoor unit is positioned higher,	10m or less	H
	When the outdoor unit is positioned lower,	10m or less	H



The use restrictions appearing in the table above are applicable to the standard pipe size combinations shown in the table below.

CAUTION

2) Determination of pipe size

Determine refrigerant pipe size pursuant to the following guidelines based on the indoor unit specifications.

	Model SRC20~35DXC09.12		Model SRC50DXC18	
	Gas pipe	Liquid pipe	Gas pipe	Liquid pipe
Outdoor unit connected	ø9.52 Flare	ø6.35 Flare	ø12.7 Flare	ø6.35 Flare
	ø9.52	ø6.35	ø12.7	ø6.35
Indoor unit connected	ø9.52	ø6.35	ø12.7	ø6.35

3) Refrigerant pipe wall thickness and material

- Select refrigerant pipes of the table shown on the right wall thickness and material as specified for each pipe size.

NOTE Select pipes having a wall thickness larger than the specified minimum pipe thickness.

Pipe diameter [mm]	ø6.35	ø9.52	ø12.7
Minimum pipe wall thickness [mm]	0.8	0.8	0.8
Pipe material*	O-type pipe	O-type pipe	O-type pipe


*Phosphorus deoxidized seamless copper pipe (CS 23.040.15, ICS 77.150.30)

When pipe is brazing.

About brazing

Brazing must be performed under a nitrogen gas flow.

Without nitrogen gas, a large quantity of foreign matters (oxidized film) are created, causing a critical failure from capillary tube or expansion valve clogging.



4) On-site piping work


Take care so that installed pipes may not touch components within a unit.

If touching with an internal component, it will generate abnormal sounds and/or vibrations.

Please remove the screw of a side cover and remove to the front.

How to remove the side cover

- Carry out the on-site piping work with the service valve fully closed.
- Give sufficient protection to a pipe end (compressed and blazed, or with an adhesive tape) so that water or foreign matters may not enter the piping.
- Bend a pipe to a radius as large as practical (R100~R150). Do not bend a pipe repeatedly to correct its form.
- Flare connection is used between the unit and refrigerant pipe. Flare a pipe after engaging a flare nut onto it. Flare dimensions for R410A are different from those for conventional R407C. Although we recommend the use of flaring tools designed specifically for R410A, conventional flaring tools can also be used by adjusting the measurement of protrusion B with a protrusion control gauge.
- The pipe should be anchored every 1.5m or less to isolate the vibration.
- Tighten a flare joint securely.



Do not apply force beyond proper fastening torque in tightening the flare nut.

Fix both liquid and gas service valves at the valve main bodies as illustrated on the right, and then fasten them, applying appropriate fastening torque.

Service valve size (mm)	Tightening torque (N·m)	Tightening angle (°)	Recommended length of a tool handle (mm)
ø6.35 (1/4")	14~18	45~60	150
ø9.52 (3/8")	34~42	30~45	200
ø12.7 (1/2")	49~61	30~45	250




Use a torque wrench. If a torque wrench is not available, fasten the flare nut manually first and then tighten it further, using the left table as a guide.


Do not hold the valve cap area with a spanner.

5) Air tightness test

- ① Although outdoor and indoor units themselves have been tested for air tightness at the factory, check the connecting pipes after the installation work for air tightness from the service valve's check joint equipped on the outdoor unit side. While conducting a test, keep the service valve shut all the time.
 - a) Raise the pressure to 0.5MPa, and then stop. Leave it for five minutes to see if the pressure drops.
 - b) Then raise the pressure to 1.5MPa, and stop. Leave it for five more minutes to see if the pressure drops.
 - c) Then raise the pressure to the specified level (4.15MPa), and record the ambient temperature and the pressure.
 - d) If no pressure drop is observed with an installation pressurized to the specified level and left for about one day, it is acceptable. When the ambient temperature fall 1°C, the pressure also fall approximately 0.01MPa. The pressure, if changed, should be compensated for.
 - e) If a pressure drop is observed in checking e) and a) – d), a leak exists somewhere. Find a leak by applying bubble test liquid to welded parts and flare joints and repair it. After repair, conduct an air tightness test again.
- ② In conducting an air tightness test, use nitrogen gas and pressurize the system with nitrogen gas from the gas side. Do not use a medium other than nitrogen gas under any circumstances.



6) Evacuation



Pay attention to the following points in addition to the above for the R410A and compatible machines.

- To prevent a different oil from entering, assign dedicated tools, etc. to each refrigerant type. Under no circumstances must a gauge manifold and a charge hose in particular be shared with other refrigerant types (R22, R407C, etc.).
- Use a counterflow prevention adapter to prevent vacuum pump oil from entering the refrigerant system.

7) Additional refrigerant charge (Model SRC50/DXC18)

(1) Calculate a required refrigerant charge volume from the following table.

Model	Additional charge volume (kg) per meter of refrigerant piping (liquid pipe ø6.35)	Refrigerant volume charged for shipment at the factory (kg)	Installation's pipe length (m) covered without additional refrigerant charge
Model SRC50/DXC18	0.02	1.35	15

- This unit contains factory charged refrigerant covering 15m of refrigerant piping and additional refrigerant charge on the installation site is not required for an installation with up to 15m refrigerant piping.
- When refrigerant piping exceeds 15m, additionally charge an amount calculated from the pipe length and the above table for the portion in excess of 15m.

Formula to calculate the volume of additional refrigerant required



$$\text{Additional charge volume (kg)} = (\text{Main length (m)} - \text{Factory charged volume 15 (m)}) \times 0.02 \text{ (kg/m)}$$

- When an additional charge volume calculation result is negative, it is not necessary to charge refrigerant additionally.
- For an installation measuring 15m or shorter in pipe length, please charge the refrigerant volume charged for shipment at the factory, when you recharge refrigerant after servicing etc.

8) Heating and condensation prevention

- (1) Heating refrigerant pipes (both gas and liquid pipes) for heat insulation and prevention of dew condensation.
 - Improper heat insulation/anti-dew dressing can result in a water leak or dripping causing damage to household effects, etc.
- (2) Use a heat insulating material that can withstand 120°C or a higher temperature. Poor heat insulating capacity can cause heat insulation problems or cable deterioration.
 - All gas pipes must be securely heat insulated in order to prevent damage from dripping water that comes from the condensation formed on them during a cooling operation or personal injury from burns because their surface can reach quite a high temperature due to discharged gas flowing inside during a heating operation.
 - Wrap indoor units' flare joints with heat insulating parts (pipe cover) for heat insulation (both gas and liquid pipes).
 - Give heat insulation to both gas and liquid side pipes. Bundle a heat insulating material and a pipe tightly together so that no gaps may be left between them and wrap them together with a connecting cable by a dressing tape.
 - Both gas and liquid pipes need to be dressed with 20mm or thicker heat insulation materials above the ceiling where relative humidity exceeds 70%.

Band (procured locally)




(2) Charging refrigerant

- Since R410A refrigerant must be charged in the liquid phase, you should charge it, keeping the container cylinder upside down or using a refrigerant cylinder equipped with a siphon tube.
- Charge refrigerant always from the liquid side service port with the service valve shut. When you find it difficult to charge a required amount, fully open the outdoor unit valves on both liquid and gas sides and charge refrigerant from the gas (suction) side service port, while running the unit in the cooling mode. In doing so, care must be taken so that refrigerant may be discharged from the cylinder in the liquid phase all the time. When the cylinder valve is throttled down or a dedicated conversion tool to change liquid phase refrigerant into mist is used to protect the compressor, however, adjust charge conditions so that refrigerant will gasify upon entering the unit.
- In charging refrigerant, always charge a calculated volume by using a scale to measure the charge volume.
- When refrigerant is charged with the unit being run, complete a charge operation within 30minutes. Running the unit with an insufficient quantity of refrigerant for a long time can cause a compressor failure.

NOTE Put down the refrigerant volume calculated from the pipe length onto the caution label attached on the service panel.


3. DRAIN PIPING WORK

- Execute drain piping by using a drain elbow and drain grommets supplied separately as accessories, where water drained from the outdoor unit is a problem.
- Water may drip where there is a larger amount of drain water. Seal around the drain elbow and drain grommets with putty or adequate caulking material.
- Condensed water may flow out from vicinity of service valve or connected pipes.
- Where you are likely to have several days of sub-zero temperatures in a row, do not use a drain elbow and drain grommets. (There is a risk of drain water freezing inside and blocking the drain.)




CAUTION

Do not put a grommet on this hole.
This is a supplementary drain hole to discharge drain water, when a large quantity of it is gathered.



- When condensed water needs to be led to a drain, etc., install the unit on a flat base (supplied separately as an optional part) or concrete blocks. Then, please secure space for the drain elbow and the drain hose.



4. ELECTRICAL WIRING WORK

For details of electrical cabling, refer to the indoor unit installation manual.

Electrical installation work must be performed by an electrical installation service provider qualified by a power provider of the country.

Electrical installation work must be executed according to the technical standards and other regulations applicable to electrical installations in the country.

- Do not use any supply cord lighter than one specified in parentheses for each type below.
- braided cord (code designation 60245 IEC 51)
- ordinary tough rubber sheathed cord (code designation 60245 IEC 53)
- flat twin tinsel cord (code designation 60227 IEC 41)
- Use polychloroprene sheathed flexible cord (code designation 60245 IEC57) for supply cords of parts of appliances for outdoor use.
- Ground the unit. Do not connect the grounding wire to a gas pipe, water pipe, lightning rod or telephone grounding wire.

If improperly grounded, an electric shock or malfunction may result.

- A grounding wire must be connected before connecting the power cable. Provide a grounding wire longer than the power cable.
- The installation of an impulse withstanding type earth leakage breaker is necessary. A failure to install an earth leakage breaker can result in an accident such as an electric shock or a fire.

Do not turn on the power until the electrical work is completed.

- Do not use a condensive capacitor for power factor improvement under any circumstances. (It does not improve power factor, while it can cause an abnormal overheat accident)

For power supply cables, use conduits.

- Do not lay electronic control cables (wireless remote control and signaling wires) and other cables together outside the unit. Laying them together can result in the malfunctioning or a failure of the unit due to electric noises.

Fasten cables so that they may not touch the piping, etc.

- When cables are connected, make sure that all electrical components within the electrical component box are free of loose connector coupling or terminal connection and then attach the cover securely. (Improper cover attachment can result in malfunctioning or a failure of the unit, if water penetrates into the box.)

Never use a shield cable.

- SRC-ZMA-S, SRC-ZMA-S and DXC-ZMA-S complies with the DRED (Demand Response Enabling Devices) standard AS/NZS4755.3.1 and supports demand response modes 1, 2, and 3 (DRM1, 2, and 3). Since the air conditioner limits the electric power or energy by receiving the DRED input signal, the sense of cooling operation or heating operation may deteriorate over time. The outdoor unit of this air conditioner is equipped with a terminal block for DRED input and supports ELV (Extra-Low Voltage) complying with AS/NZS60335.1.

CAUTION

In case of faulty wiring connection, the indoor unit stops, and then the run lamp turns on and the timer lamp blinks.


Use cables for interconnection wiring to avoid loosening of the wires.
CENELEC code for cables Required field cables.

H05RNRF4G1.5 (Example) or 245IEC57


H	Harmonized cable type
05	300/500 volts
R	Natural-and/or synth. rubber wire insulation
N	Polychloroprene rubber conductors insulation
R	Stranded core
4x1.5	Number of conductors
G	One conductor of the cable is the earth conductor (yellow/green)
1.5	Section of copper wire (mm ²)

Power cable, indoor - outdoor connecting wire circuit diagram


Model SRC20~35ZM-S
Model SRC20~35ZMX-S





Model SRC20~35ZMA-S
Model SRC20~35ZMXA-S
Model DXC09, 12ZMA-S




Model SRC50ZM-S



Model SRC50ZMA-S
Model DXC18ZMA-S



Power cable, indoor-outdoor connecting wires



- Always perform grounding system installation work with the power cord unplugged.
- Connect a pair bearing a common terminal number with an indoor-outdoor connecting wire.
- In cabling, fasten cables securely with cable clamps so that no external force may work on terminal connections.
- Grounding terminals are provided in the control box.


Always use an earth leakage circuit breaker designed for inverter circuits to prevent a faulty operation.

Phase	Earth leakage breaker	Switchgear or Circuit Breaker		Interconnecting and grounding wires (minimum)
		Switch breaker	Over current protector rated capacity	
Single-phase	15A, 30mA, 0.1sec or less	30A	16A	2.0mm ²
				1.5mm ² X 4

- The specifications shown in the above table are for units without heaters. For units with heaters, refer to the installation instructions or the construction instructions of the indoor unit.
- Switchgear or Circuit breaker capacity which is calculated from MAX. over current should be chosen along the regulations in each country.
- The cable specifications are based on the assumption that a metal or plastic conduit is used with no more than three cables contained in a conduit and a voltage drop is 2%. For an installation falling outside of these conditions, please follow the internal cabling regulations. Adapt it to the regulation in effect in each country.

5. UTILIZATION OF EXISTING PIPING

Check whether an existing pipe system is reusable or not by using the following flow chart.



<Table of pipe size restrictions>

◎: Standard pipe size

Pipe Size	Additional charge volume per meter of pipe
20-35	0.02kg/m
	Gas pipe
	Usability
	Maximum one-way pipe length
	Length covered without additional charge
	10

- Please consult with our distributor in the area, if you need to recover refrigerant and charge it again.
- Any combinations of pipe sizes not listed in the table are not usable.

WARNING

<Where the existing unit can be run for a cooling operation.>

Carry out the following steps with the existing unit (in the order of (1), (2), (3) and (4))

- (1) Run the unit for 30 minutes for a cooling operation.
 - (2) Stop the indoor fan and run the unit for 3 minutes for a cooling operation (returning liquid)
 - (3) Close the liquid side service valve of the outdoor unit and pump down (refrigerant recovery)
 - (4) Blow with nitrogen gas. ※ If discolored refrigeration oil or any foreign matters is discharged by the blow, wash the pipe system or install a new pipe system.
 - For the flare nut, do not use the old one, but use the one supplied with the outdoor unit. Process a flare to the dimensions specified for R410A.
- <Where the existing unit cannot be run for a cooling operation.>
- Wash the pipe system or install a new pipe system.
- If you choose to wash the pipe system, please contact our distributor in the area.

INSTALLATION TEST CHECK POINTS

Check the following points again after completion of the installation, and before turning on the power. Conduct a test run again and ensure that the unit operates properly. Explain to the customer how to use the unit and how to take care of the unit following the instruction manual.

After installation



- ☐ Power cables and connecting wires are securely fixed to the terminal block.
- ☐ The power supply voltage is correct as the rating.
- ☐ The drain hose is fixed securely.
- ☐ Service valve is fully open.
- ☐ No gas leaks from the joints of the service valve.
- ☐ The pipe joints for indoor and outdoor pipes have been insulated.
- ☐ The reverse flow check cap is attached.
- ☐ The cover of the pipe cover (A) faces downward to prevent rain from entering.
- ☐ Gaps are properly sealed between the pipe covers (A) (B) and the wall surface / pipes.
- ☐ The screw of the side cover is tightened securely.

9. OPTION PARTS

(1) Wired remote control (RC-E5)

Read together with indoor unit's installation manual.



⚠ WARNING

- Fasten the wiring to the terminal securely and hold the cable securely so as not to apply unexpected stress on the terminal.
Loose connection or hold will cause abnormal heat generation or fire. 
- Make sure the power supply is turned off when electric wiring work.
Otherwise, electric shock, malfunction and improper running may occur. 

⚠ CAUTION

- DO NOT install the remote control at the following places in order to avoid malfunction.


(1) Places exposed to direct sunlight	(4) Hot surface or cold surface enough to generate condensation
(2) Places near heat devices	(5) Places exposed to oil mist or steam directly
(3) High humidity places	(6) Uneven surface


- DO NOT leave the remote control without the upper case.
In case the upper case needs to be detached, protect the remote control with a packaging box or bag in order to keep it away from water and dust. 

Accessories	Remote control, wood screw (ø3.5×16) 2 pieces
Prepare on site	Remote control cord (2 cores) the insulation thickness in 1mm or more. [In case of embedding cord] Electrical box, M4 screw (2 pieces) [In case of exposing cord] Cord clamp (if needed)


Installation procedure

- ① Open the cover of remote control, and remove the screw under the buttons without fail.
- ② Remove the upper case of remote control.
Insert a flat-blade screwdriver into the dented part of the upper part of the remote control, and wrench slightly.





[In case of embedding cord]

- ③ Embed the electrical box and remote control cord beforehand.





- ④ Prepare two M4 screws (recommended length is 12-16mm) on site, and install the lower case to electrical box. Choose either of the following two positions in fixing it with screws.



- ⑤ Connect the remote control cord to the terminal block.
Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y). (X and Y are no polarity)


- ⑥ Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.




[In case of exposing cord]

- ③ You can pull out the remote control cord from left upper part or center upper part.
Cut off the upper thin part of remote control lower case with a nipper or knife, and grind burrs with a file etc.

- ④ Install the lower case to the flat wall with attached two wooden screws.



- ⑤ Connect the remote control cord to the terminal block.
Connect the terminal of remote control (X,Y) with the terminal of indoor unit (X,Y).
(X and Y are no polarity)
Wiring route is as shown in the right diagram depending on the pulling out direction.




The wiring inside the remote control case should be within 0.3mm^2 (recommended) to 0.5mm^2 .

The sheath should be peeled off inside the remote control case.

The peeling-off length of each wire is as below.

Pulling out from upper left	Pulling out from upper center
X wiring : 215mm	X wiring : 170mm
Y wiring : 195mm	Y wiring : 190mm




- ⑥ Install the upper case as before so as not to catch up the remote control cord, and tighten with the screws.
- ⑦ In case of exposing cord, fix the cord on the wall with cord clamp so as not to slack.

Installation and wiring of remote control

- ① Wiring of remote control should use $0.3\text{mm}^2 \times 2$ core wires or cables. (on-site configuration)
- ② Maximum prolongation of remote control wiring is 600 m.
If the prolongation is over 100m, change to the size below.
But, wiring in the remote control case should be under 0.5mm^2 . Change the wire size outside of the case according to wire connecting. Waterproof treatment is necessary at the wire connecting section. Be careful about contact failure.
- 100 - 200m..... $0.5\text{mm}^2 \times 2$ cores
Under 300m..... $0.75\text{mm}^2 \times 2$ cores
Under 400m..... $1.25\text{mm}^2 \times 2$ cores
Under 600m..... $2.0\text{mm}^2 \times 2$ cores

Master/ slave setting when more than one remote controls are used

A maximum of two remote controls can be connected to one indoor unit (or one group of indoor units.)



Set SW1 to "Slave" for the slave remote control. It was factory set to "Master" for shipment.

Note: The setting "Remote control thermistor enabled" is only selectable with the master remote control in the position where you want to check room temperature.

The air conditioner operation follows the last operation of the remote control regardless of the master/ slave setting of it.

The indication when power source is supplied


When power source is turned on, the following is displayed on the remote control until the communication between the remote control and indoor unit settled.

Master remote control : " WAIT " M

Slave remote control : " WAIT " S

At the same time, a mark or a number will be displayed for two seconds first.


This is the software's administration number of the remote control, not an error cord.



※ The left mark is only an example. Other marks may appear.

When remote control cannot communicate with the indoor unit for half an hour, the below indication will appear.

Check wiring of the indoor unit and the outdoor unit etc.



The range of temperature setting

When shipped, the range of set temperature differs depending on the operation mode as below.

Heating : 16-30°C (55-86°F)

Except heating (cooling, fan, dry, automatic) : 18-30°C (62-86°F)

●Upper limit and lower limit of set temperature can be changed with remote control.

Upper limit setting: valid during heating operation. Possible to set in the range of 20 to 30°C (68 to 86°F).

Lower limit setting: valid except heating (automatic, cooling, fan, dry) Possible to set in the range of 18 to 26°C (62 to 79°F).

When you set upper and lower limit by this function, control as below.

- When ⑫ TEMP RANGE SET, remote control function of function setting mode is "INDN CHANGE" (factory setting),

【 If upper limit value is set 】

During heating, you cannot set the value exceeding the upper limit.

【 If lower limit value is set 】

During operation mode except heating, you cannot set the value below the lower limit.

- When ⑫ TEMP RANGE SET, remote control function of function setting mode is "NO INDN CHANGE"

【 If upper limit value is set 】

During heating, even if the value exceeding the upper limit is set, upper limit value will be sent to the indoor unit.

But, the indication is the same as the temperature set.

【 If lower limit value is set 】


During except heating, even if the value lower than the lower limit is set, lower limit value will be sent to the indoor unit.

But, the indication is the same as the temperature set.

●How to set upper and lower limit value

- Stop the air-conditioner, and press (SET) and (MODE) button at the same time for over three seconds .
The indication changes to "FUNCTION SET ▼".
- Press button once, and change to the "TEMP RANGE ▲" indication.
- Press (SET) button, and enter the temperature range setting mode.
- Select "UPPER LIMIT ▼" or "LOWER LIMIT ▲" by using button.
- Press (SET) button to fix.
- When "UPPER LIMIT ▼" is selected (valid during heating)
 - ① Indication: " ▼ ^ SET UP" → "UPPER 30°C ▼"
 - ② Select the upper limit value with temperature setting button . Indication example: "UPPER 26°C ▼ ^" (blinking)
 - ③ Press (SET) button to fix. Indication example: "UPPER 26°C" (Displayed for two seconds)
After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".
- When "LOWER LIMIT ▲" is selected (valid during cooling, dry, fan, automatic)
 - ① Indication: " ▼ ^ SET UP" → "LOWER 18°C ^"
 - ② Select the lower limit value with temperature setting button . Indication example: "LOWER 24°C ▼ ^" (blinking)
 - ③ Press (SET) button to fix. Indication for example: "LOWER 24°C" (Displayed for two seconds)
After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".
- Press button to finish.

- It is possible to finish by pressing button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.



The functional setting

- The initial function setting for typical using is performed automatically by the indoor unit connected, when remote control and indoor unit are connected.
- As long as they are used in a typical manner, there will be no need to change the initial settings.
- If you would like to change the initial setting marked "○", set your desired setting as for the selected item.
- The procedure of functional setting is shown as the following diagram.

[Flow of function setting]

Start : Stop air-conditioner and press " (○) " (SET) and " (⇐) " (MODE) buttons at the same time for over three seconds.

Finalize : Press " (○) " (SET) button.

Reset : Press " (⇐) " (RESET) button.

Select : Press " (▲) " (UP) button.

End : Press " (ON/OFF) " button.

Record and keep the setting

Consult the technical data etc. for each control details

It is possible to finish above setting on the way, and unfinished change of setting is unavailable.

* ○ : Initial settings
* ※ : Automatic criterion

Stop air-conditioner and press " (○) " (SET) + " (⇐) " (MODE) buttons at the same time for over three seconds.

FUNCTION SET ▼

To next page

FUNCTION ▼ (Remote control function)

Function	setting		
01 ESP SET	ESP VALID	○	Validate setting of ESP: External Static Pressure
	ESP INVALID		Invalidate setting of ESP
02 AUTO RUN SET	AUTO RUN ON	※	Automatic operation is impossible
	AUTO RUN OFF	※	
03 TEMP SW	TEMP VALID	○	Temperature setting button is not working
	TEMP INVALID		
04 MODE SW	MODE VALID	○	Mode button is not working
	MODE INVALID		
05 ON/OFF SW	ON/OFF VALID	○	On/Off button is not working
	ON/OFF INVALID		
06 FAN SPEED SW	FAN SPEED VALID	※	Fan speed button is not working
	FAN SPEED INVALID	※	
07 LOUVER SW	LOUVER VALID	※	Louver button is not working
	LOUVER INVALID	※	
08 TIMER SW	TIMER VALID	○	Timer button is not working
	TIMER INVALID		
09 SENSOR SET	SENSOR OFF	○	Remote thermistor is not working.
	SENSOR ON		Remote thermistor is working.
	SENSOR +3.0℃		Remote thermistor is working, and to be set for producing +3.0℃ increase in temperature.
	SENSOR +2.0℃		Remote thermistor is working, and to be set for producing +2.0℃ increase in temperature.
	SENSOR +1.0℃		Remote thermistor is working, and to be set for producing +1.0℃ increase in temperature.
	SENSOR -1.0℃		Remote thermistor is working, and to be set for producing -1.0℃ increase in temperature.
	SENSOR -2.0℃		Remote thermistor is working, and to be set for producing -2.0℃ increase in temperature.
	SENSOR -3.0℃		Remote thermistor is working, and to be set for producing -3.0℃ increase in temperature.
10 AUTO RESTART	INVALID	○	In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), the operation of ventilation device is linked with the operation of indoor unit.
	VALID		
* 11 VENT LINK SET	NO VENT	○	
	VENT LINK		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), you can operate /stop the ventilation device independently by (VENT) button.
	NO VENT LINK		In case of Single split series, by connecting ventilation device to CNT of the indoor printed circuit board (in case of VRF series, by connecting it to CND of the indoor printed circuit board), you can operate /stop the ventilation device independently by (VENT) button.
12 TEMP RANGE SET	INDIC CHANGE	○	If you change the range of set temperature, the indication of set temperature will vary following the control.
	NO INDIC CHANGE		If you change the range of set temperature, the indication of set temperature will not vary following the control, and keep the set temperature.
13 FAN	HI-MID-LO	※	Airflow of fan becomes of or the four speed of .
	HI-LO	※	
	HI-MID	※	
	1 FAN SPEED	※	
14 POSITION	4 POSITION STOP	○	If you change the remote control function "14 POSITION" you must change the indoor function "04 POSITION" accordingly.
	FREE STOP		
15 MODEL TYPE	HEAT PUMP	※	The louver can stop at any position.
	COOLING ONLY	※	
16 EXTERNAL CONTROL SET	INDIVIDUAL	○	If you input signal into CNT of the indoor printed circuit board from external, the indoor unit will be operated independently according to the input from external.
	FOR ALL UNITS		
17 ROOM TEMP INDICATION SET	INDICATION OFF	○	In normal working indication, indoor unit temperature is indicated instead of airflow. (Only the master remote control can be indicated.)
	INDICATION ON		
18 INDICATION	INDICATION ON	○	Heating preparation indication should not be indicated.
	INDICATION OFF		
19 SET	℃	○	Temperature indication is by degree C
	℉		Temperature indication is by degree F

To next page

Note (1)*The mark cannot use SRK series.

(ON/OFF) button
(finished)

Note 1: The initial setting marked "※" is decided by connected indoor and outdoor unit, and is automatically defined as following table.

Function No.	Item	Default	Model
Remote control function02	AUTO RUN SET	AUTO RUN ON	"Auto-RUN" mode selectable indoor unit.
		AUTO RUN OFF	Indoor unit without "Auto-RUN" mode
Remote control function06	FAN SPEED SW	2-STEP VALID	Indoor unit with two or three step of air flow setting
		1-STEP INVALID	Indoor unit with only one of air flow setting
Remote control function07	LOUVER SW	2-STEP VALID	Indoor unit with automatically swing louver
		1-STEP INVALID	Indoor unit without automatically swing louver
Remote control function13	I/U FAN	HI-MID-LO	Indoor unit with three step of air flow setting
		HI-LO	Indoor unit with two step of air flow setting
		HI-MID	
		1 FAN SPEED	Indoor unit with only one of air flow setting
Remote control function15	MODEL TYPE	HEAT PUMP	Heat pump unit
		COOLING ONLY	Exclusive cooling unit

Note 3: As for plural indoor unit, set indoor functions to each master and slave indoor unit.

But only master indoor unit is received the setting change of indoor unit function "05 EXTERNAL INPUT" and "06 PERMISSION / PROHIBITION".

From previous page

Indoor unit No. are indicated only when
(Indoor unit function) I/U FUNCTION ▲ plural indoor units are connected.

To set other indoor unit, press
[AIRCON NO.] button, which
allows you to go back to the indoor
unit selection screen
(for example: I/U 000 ▲).

Function	setting
*02 FAN SPEED SET	STANDARD ※ HIGH SPEED 1 ※ HIGH SPEED 2
*03 FILTER SIGN SET	INDICATION OFF TYPE 1 ○ TYPE 2 TYPE 3 TYPE 4
*04 POSITION	4 POSITION STOP ○ FREE STOP
*05 EXTERNAL INPUT	LEVEL INPUT ○ PULSE INPUT
*06 PERMISSION/PROHIBITION	INVALID ○ VALID
*07 EMERGENCY STOP	INVALID ○ VALID
*08 ※ SP OFFSET	OFFSET +3.0℃ OFFSET +2.0℃ OFFSET +1.0℃ NO OFFSET ○
*09 RETURN AIR TEMP	OFFSET +2.0℃ OFFSET +1.5℃ OFFSET +1.0℃ NO OFFSET ○ OFFSET -1.0℃ OFFSET -1.5℃ OFFSET -2.0℃
*10 ※ FAN CONTROL	LOW FAN SPEED ○ SET FAN SPEED INTERMITTENCE FAN OFF
*11 FROST PREVENTION TEMP	TEMP HIGH TEMP LOW ○
*12 FROST PREVENTION CONTROL	FAN CONTROL ON ○ FAN CONTROL OFF
*13 DRAIN PUMP LINK	※○ AND ※ ※○ AND ※ AND ※ ※○ AND ※
*14 ※ FAN REMAINING	NO REMAINING ○ 0.5 HOUR 1 HOUR 6 HOUR
*15 ※ FAN REMAINING	NO REMAINING ○ 0.5 HOUR 2 HOUR 6 HOUR
*16 ※ FAN INTERMITTENCE	NO REMAINING ○ 2min OFF 5min ON 5min OFF 5min ON
*17 PRESSURE CONTROL	STANDARD ※ TYPE1 ※

Note2: Fan setting of "HIGH SPEED"	
Fan tap	Indoor unit air flow setting
FAN SPEED SET	STANDARD UH - Hi - Me - Lo Hi - Me - Lo Hi - Lo Hi - Me
HIGH SPEED1, 2	UH - UH - Hi - Me UH - Hi - Me UH - Me UH - Hi

Initial function setting of some indoor unit is "HIGH SPEED".

4 speed is not able to be set with wireless remote control.

The filter sign is indicated after running for 180 hours.
The filter sign is indicated after running for 600 hours.
The filter sign is indicated after running for 1000 hours.
The filter sign is indicated after running for 1000 hours, then the indoor unit will be stopped by compulsion after 24 hours.

If you change the indoor function "04 POSITION",
you must change the remote control function "14 POSITION" accordingly.
You can select the louver stop position in the four.

The louver can stop at any position.

Permission/prohibition control of operation will be valid.

With the VRF series, it is used to stop all indoor units connected with the same outdoor unit immediately.
When stop signal is inputted from remote on-off terminal "CNT-6", all indoor units are stopped immediately.

To be reset for producing +3.0℃ increase in temperature during heating.
To be reset for producing +2.0℃ increase in temperature during heating.
To be reset for producing +1.0℃ increase in temperature during heating.

To be reset producing +2.0℃ increase in return air temperature of indoor unit.
To be reset producing +1.5℃ increase in return air temperature of indoor unit.
To be reset producing +1.0℃ increase in return air temperature of indoor unit.

To be reset producing -1.0℃ increase in return air temperature of indoor unit.
To be reset producing -1.5℃ increase in return air temperature of indoor unit.
To be reset producing -2.0℃ increase in return air temperature of indoor unit.

When heating thermostat is OFF, fan speed is low speed.
When heating thermostat is OFF, fan speed is set speed.

When heating thermostat is OFF, fan speed is operated intermittently.
When heating thermostat is OFF, the fan is stopped.
When the remote thermostat is working, "FAN OFF" is set automatically.
Do not set "FAN OFF" when the indoor unit's thermostat is working.

Change of indoor heat exchanger temperature to start frost prevention control.

Working only with the Single split series.
To control frost prevention, the indoor fan tap is raised.

Drain pump is run during cooling and dry.
Drain pump is run during cooling, dry and heating.
Drain pump is run during cooling, dry, heating and fan.
Drain pump is run during cooling, dry and fan.

After cooling is stopped, the fan does not perform extra operation.
After cooling is stopped, the fan perform extra operation for half an hour.
After cooling is stopped, the fan perform extra operation for an hour.
After cooling is stopped, the fan perform extra operation for six hours.

After heating is stopped or heating thermostat is OFF, the fan does not perform extra operation.
After heating is stopped or heating thermostat is OFF, the fan perform extra operation for half an hour.
After heating is stopped or heating thermostat is OFF, the fan perform extra operation for two hours.
After heating is stopped or heating thermostat is OFF, the fan perform extra operation for six hours.

During heating is stopped or heating thermostat is OFF, the fan perform intermittent operation for five minutes with low fan speed after twenty minutes' OFF.
During heating is stopped or heating thermostat is OFF, the fan perform intermittent operation for five minutes with low fan speed after five minutes' OFF.

Connected "OA Processing" type indoor unit, and is automatically defined.


From previous page

How to set function

1. Stop air-conditioner and press (SET) (MODE) buttons at the same time for over three seconds, and the "FUNCTION SET ▼" will be displayed.




2. Press (SET) button.
3. Make sure which do you want to set, "FUNCTION ▼" (remote control function) or "I/U FUNCTION ▲" (indoor unit function).
4. Press or button.
Select "FUNCTION ▼" (remote control function) or "I/U FUNCTION ▲" (indoor unit function).




5. Press (SET) button.

6. 【On the occasion of remote control function selection】


- ① "DATA LOADING" (Indication with blinking)
↓
Display is changed to "01 ESP SET".
- ② Press or button.
"No. and function" are indicated by turns on the remote control function table, then you can select from them.
(For example)



- ③ Press (SET) button.
The current setting of selected function is indicated.
(for example) "AUTO RUN ON" ← If "02 AUTO RUN SET" is selected




- ④ Press or button.
Select the setting.



- ⑤ Press (SET) button.
"SET COMPLETE" will be indicated, and the setting will be completed.
Then after "No. and function" indication returns, Set as the same procedure if you want to set continuously, and if to finish, go to 7.




7. Press (ON/OFF) button.
Setting is finished.

**【On the occasion of indoor unit function selection】**


- ① "DATA LOADING" (Blinking for 2 to 23 seconds to read the data)
↓
Indication is changed to "02 FAN SPEED SET".
Go to ②.

[Note]


- (1) If plural indoor units are connected to a remote control, the indication is "I/U 000" (blinking) ← The lowest number of the indoor unit connected is indicated.



- (2) Press or button.
Select the number of the indoor unit you are to set
If you select "ALL UNIT ▼", you can set the same setting with all units.
- (3) Press (SET) button.
- ② Press or button.
"No. and function" are indicated by turns on the indoor unit function table, then you can select from them.
(For example)



- ③ Press (SET) button.
The current setting of selected function is indicated.
(For example) "STANDARD" ← If "02 FAN SPEED SET" is selected.



- ④ Press or button.
Select the setting.

- ⑤ Press (SET) button.
"SET COMPLETE" will be indicated, and the setting will be completed.
Then after "No. and function" indication returns, set as the same procedure if you want to set continuously, and if to finish, go to 7.



※ When plural indoor units are connected to a remote control, press the button, which allows you to go back to the indoor unit selection screen. (example "I/U 000 ▲")

- It is possible to finish by pressing (ON/OFF) button on the way, but unfinished change of setting is unavailable.
- During setting, if you press (RESET) button, you return to the previous screen.
- Setting is memorized in the control and it is saved independently of power failure.

【How to check the current setting】

When you select from "No. and function" and press set button by the previous operation, the "Setting" displayed first is the current setting.
(But, if you select "ALL UNIT ▼", the setting of the lowest number indoor unit is displayed.)

(2) Interface kit (SC-BIKN-E)

RKZ012A088B

Accessories included in package

Be sure to check all the accessories included in package.

No.	Part name	Quantity
①	Indoor unit's connection cable (cable length: 1.8m)	1
②	Wood screws (for mounting the interface: $\phi 4 \times 25$)	2
③	Tapping screws (for the cable clamp and the interface mounting bracket)	3
④	Interface mounting bracket	1
⑤	Cable clamp (for the indoor unit's connection cable)	1
⑥*	CNT terminal connection cable (total cable length: 0.5m)	1

* SC-BIKN-EA only

Safety precautions

Before use, please read these Safety Precautions thoroughly before installation.

- All the cautionary items mentioned below are important safety related items to be taken into consideration, so be sure to observe them at all times.

Warning Incorrect installation could lead to serious consequences such as death, major injury or environmental destruction.

- Symbols used in these precautions



Always go along these instruction.

- After completed installation, carry out trial operation to confirm no anomaly, and ask the user to keep this installation manual in a good place for future reference.



WARNING



- **Installation must be carried out by a qualified installer.**

If you install it by yourself, it may cause an electric shock, fire and personal injury, as a result of a system malfunction.

- **Install it in full accordance with the instruction manual.**

Incorrect installation may cause an electric shock, fire and personal injury.

- **Electrical work must be carried out by a qualified electrician in accordance with the technical standard for electrical equipment, the indoor wiring standard and this instruction manual.**

Incorrect installation may cause an electric shock, fire and personal injury.

- **Use the specific cables for wiring. And connect all the cables to terminals or connectors securely and clamp them with cable clamps in order for external forces not to be transmitted to the terminals directly.**


Incomplete connection may cause malfunction, and lead to heat generation and fire.

- **Use the original accessories and specified components for installation.**


If the parts other than those prescribed by us are used, it may cause an electric shock, fire and personal injury.

Connecting the indoor unit's connection cable to the interface

- ① Remove the upper case of the interface.
 - Remove 2 screws from the interface casing before removal of upper casing.
- ② Connect the indoor unit's connection cable to the interface.
 - Connect the connector of the indoor unit connection cable to the connector on the interface's circuit board.
- ③ Fix the indoor unit's connection cable with the cable clamp.
 - Cable can be brought in from the top or from the back.
 - Cut out the punch-outs for the connection cables running into the casing with cutter.
- ④ Connect the indoor unit's connection cable to the indoor control PCB.
 - Connect the indoor unit's connection cable to the indoor control PCB securely.
 - Clamp the connection cable to the indoor control box securely with the cable clamp provided as an accessory.
 - Regarding the cable connection to the indoor unit, refer to the instruction manual for indoor unit.



Name of each part of the interface



*Either the connection cables of super link E board (SC-ADNA-E) or of wired remote control is connectable.

Switch	Setting	Function	Switch	Setting	Function
SW2-1	ON**	CNT level input	SW2-3	ON**	External input (CNT input)
	OFF	CNT Pulse input		OFF	Operation permission/prohibition (CNT input)
SW2-2	ON**	Wired remote control : Enable	SW2-4	ON**	Annual cooling : Enable***
	OFF	Wired remote control : Disable		OFF	Annual cooling : Disable***

** Factory setting

*** Indoor fan control at low outdoor air temperature in cooling

Installation of the interface



- Install the interface within the range of the connection cable length from the indoor unit. (approximately 1.8m)
- Be sure not to extend the connection cable on site. If the connection cable is extended, malfunction may occur.
- Fix the interface on the wall, pillar or the like.

● DO NOT install the interface and wired remote control at the following places.

- Places exposed to direct sunlight
- Places near heating devices
- High humidity places
- Surfaces where are enough hot or cold to generate condensation
- Places exposed to oil mist or steam directly
- Uneven surface


Mounting the interface directly on a wall

- ① Mount the lower casing of the interface on a flat surface with wood screws provided as standard accessory.
- ② Mount the upper casing.




Recessing the interface in the wall

- ① Recess the electrical box (procured locally) and connection cables in the wall.
- ② Mount the lower casing of the interface to the electrical box with M4 screws (procured locally).
- ③ Mount the upper casing.



Mounting the interface with the mounting bracket

- ① Mount the mounting bracket to the interface with tapping screws provided as standard accessory.
- ② Mount the mounting bracket on wall or the like with wood screws provided as standard accessory.
- ③ Mount the mounting bracket to a wall surface, etc. using the wood screws provided.




Installation check items

- ☐ Are the connection cables connected securely to the terminal blocks and connectors?
- ☐ Are the thickness and length of the connection cables conformed with the standard?

Functions of CNT connector

It is available to operate the air conditioning unit and to monitor the operation status with the external control unit (remote display) by sending the input/output signal through CNT connector on the indoor control PCB.

- ① Connect a external remote control unit (procured locally) to CNT terminal.
- ② In case of the pulse input, switch OFF the DIP switch SW2-1 on the interface PCB.
- ③ When setting operation permission/prohibition mode, switch OFF the DIP switch SW2-3 on the interface PCB.




Input/Output	Function	Output signal		Content
		Relay	ON/OFF	
Output 1	Operation output	XR1	ON	During air-conditioner operation
Output 2	Heating output	XR2	ON	During heating operation
Output 3	Compressor operation output	XR3	ON	During compressor running
Output 4	Malfunction output	XR4	ON	During anomalous stop

- XR1-4 are for the DC 12V relay
- XR5 is a DC 12/24V or AC 220-240V relay
- CNT connector (local) maker, model

Connector	Molex	5264-06
Terminals	Molex	5263T

Input/ Output	Function	SW2-1		SW2-3			Air- Conditioner	Operation by Remote Control	
		Setting		Setting	Input signal Level/Pulse	Content			
Input	External control input	ON*	Level input	ON*	Level	OFF→ON	External input	ON	Allowed
				ON→OFF		ON→OFF		OFF	
				OFF		OFF→ON	Operation permission	OFF	
		OFF	Pulse input	ON*	Pulse	ON→OFF	Operation prohibition	OFF	Not allowed
				OFF		OFF→ON	External input	OFF→ON	
				OFF	ON→OFF	Operation permission	ON		
ON→OFF	Operation prohibition	OFF	Not allowed						

* Factory setting




Connection of super link E board

Regarding the connection of super link E board, refer to the instruction manual of super link E board.


For electrical work, power supply for all of units in the super link system must be turned OFF.

- ① Switch ON the DIP switch SW2-2 (Factory setting: ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, Temperature Setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.



- ② Wiring connection between the interface and the super link E board.



No.	Names of recommended signal wires
1	Shielded wire
2	Vinyl cabtyre round cord
3	Vinyl cabtyre round cable
4	Vinyl insulated wirevinyl sheathed cable for control

Within 200 m 0.5 mm² × 2 cores
 Within 300 m 0.75 mm² × 2 cores
 Within 400 m 1.25 mm² × 2 cores
 Within 600 m 2.0 mm² × 2 cores

- ③ Clamp the connection cables with cable clamps.


Connection of wired remote control

Regarding the connection of wired remote control, refer to the instruction manual of wired remote control.

- ① Switch ON the DIP switch SW2-2 (Factory setting : ON) on the interface PCB.

Caution: Wireless remote control attached to the indoor unit can be used in parallel, after connecting the wired remote control. However, some of functions other than the basic functions such as RUN/STOP, Temperature Setting, etc. may not work properly and may have a mismatch between the display and the actual behavior.

- ② Wiring connection between the interface and the wired remote control.



Installation and wiring of wired remote control

- ① Install the wired remote control with reference to the attached instruction manual of wired remote control.

- ② 0.3mm² × 2-core cable should be used for the wiring of wired remote control.

- ③ Maximum length of wiring is 600m.

If the length of wiring exceeds 100m, change the size of cable as mentioned below.

100m-200m: 0.5mm² × 2-core, 300m or less: 0.75mm² × 2-core, 400m or less: 1.25mm² × 2-core, 600m or less: 2.0mm² × 2-core

However, cable size connecting to the terminal of wired remote control should not exceed 0.5mm². Accordingly if the size of connection cable exceeds 0.5mm², be sure to downsize it to 0.5mm² at the nearest section of the wired remote control and waterproof treatment should be done at the connecting section in order to avoid contact failure.

- ④ Don't use the multi-core cable to avoid malfunction.

- ⑤ Keep the wiring of wired remote control away from grounding (Don't touch it to any metal frame of building, etc.).

- ⑥ Connect the connection cables to the terminal blocks of the wired remote control and the interface securely (no polarity).

- ③ Clamp the connection cables with cable clamps.

Control of multiple units by a single wired remote control

Multiple units (up to 16) can be controlled by a single wired remote control.

In this case, all units connected with a single wired remote control will operate under the same mode and same setting temperature.


- ① Connect all the interface with 2-core cables of wired remote control line.

- ② Set the address of indoor unit for remote control communication from "0" to "F" with the rotary switch SW1 on the interface PCB.

- ③ After turning the power ON, the address of indoor unit can be displayed by pressing [AIR CON] button on the wired remote control.

Make sure all indoor units connected are displayed in order by pressing

▲ or ▼ button.



Master/Slave setting wired when 2 of wired remote control are used

Maximum two wired remote control can be connected to one indoor unit (or one group of indoor units)

- ① Set the DIP switch SW1 on the wired remote control to "Slave" for the slave remote control. (Factory setting : Master)

○ Caution : Remote control sensor is invalid.

- When using the wireless remote control in parallel with the wired remote control;

Since temperature setting range of wired remote control is different from that of wireless remote control, please adjust the setting range of wired remote control to be the same setting range of wireless remote control by following procedure. (The set temperature may not be displayed correctly on the wireless remote control, unless change of temperature setting range is done.)

Changing procedure of temperature setting range is as follows.

How to set upper and lower limit of temperature sting range

1. Stop the air-conditioner, and press (SET) and (MODE) button at the same time for 3 seconds or more.

The indication changes to "FUNCTION SET ▼"

2. Press (▼) button once, and change to the "TEMP RANGE ▲" indication.

3. Press (SET) button, and enter the temperature range setting mode.

4. Confirm that the "Upper limit ▼" is shown on the display.

5. Press (SET) button to fix.

6. ① Indication: "UPPER 28°C ▲" → "UPPER 28°C ▼"

② Select the upper limit value 30°C with temperature setting button [▲]. "UPPER 30°C ▼" (blinking)

- ③ Press (SET) button to fix. "UPPER 30°C" (Displayed for two seconds)

After the fixed upper limit value displayed for two seconds, the indication will return to "UPPER LIMIT ▼".

7. Press (▼) button once, "LOWER LIMIT ▲" is selected, press (SET) button to fix.

① Indication: "UPPER 30°C ▼" → "LOWER 20°C ▲"

② Select the lower limit value 18°C with temperature setting button [▲]. "LOWER 18°C ▲" (blinking)


- ③ Press (SET) button to fix. "LOWER 18°C" (Displayed for two seconds)

After the fixed lower limit value displayed for two seconds, the indication will return to "LOWER LIMIT ▼".

8. Press [ON/OFF] button to finish.

Temperature setting range

Mode	Temperature setting range
Cooling, Heating, Dry, Auto	18-30°C



• It is possible to quit in the middle by pressing [ON/OFF] button, but the change of setting is incomplete.

• During setting, if pressing (RESET) button, it returns to the previous screen.

(3) Super link E board (SC-ADNA-E)

PJZ012D029F

- Read and understand the instructions completely before starting installation.
- Refer to the instructions for both indoor and outdoor units.

Safety precautions

- Carefully read "Safety precautions" first. Follow the instructions for installation.
- Precautions are grouped into "Warning⚠" and "Caution⚠". The "Warning⚠" group includes items that may lead to serious injury or death if not observed. The items included in the "Caution⚠" group also may lead to serious results under certain conditions. Both groups are crucial for safety installation. Read and understand them carefully.
- After installation, conduct the test operation of the device to check for any abnormalities. Describe how to operate the device to the customer following the installation instruction manual. Instruct the customer to keep this installation instruction for future reference.

⚠ WARNING

- This device should be installed by the dealer where you purchase the device or a licensed professional shop. If the device is incorrectly installed by the customer, it may result in electric shock or fire.
- Install the device carefully following the installation instruction. If the device is incorrectly installed, it may result in electric shock or fire.
- Use the accessory parts and specified parts for installation. If any parts that do not match the specifications are used, it may result in electric shock or fire.
- A person with the electrical service certification should conduct the service based on the "Technical standards for electrical facilities", "Electrical Wiring Code", and the installation instruction. If the work is done incorrectly, it may result in electric shock or fire.
- Wiring should be securely connected using the specified types of wire. No external force on the wire should be applied to any terminals. If a secure connection is not achieved, it may result in electric shock or fire.









⚠ CAUTION

- Provide ground connection.
The ground line should never be connected to the gas supply piping, the water supply piping, the lightning conductor rod, nor the telephone ground. If the grounding is improper, it may result in electric shock.
- Do not install the device in the following locations.
 1. Where there is mist/spray of oil or steam such as kitchens.
 2. Where there is corrosive gases such as sulfurous acid gas.
 3. Where there is a device generating electromagnetic waves.
These may interfere with the control system resulting in the device becoming uncontrollable.
 4. Where flammable volatile materials such as paint thinner and gasoline may exist or where they are handled. This may cause a fire.

1 Application

Indoor-to-outdoor three core communication specification type 3 (since October 2007)


2 Accessories

SL E board 	Metal box 	Metal cover 	Screw for Ground M4x8L 2 pieces 
Pan head screws φ4x8L 2 pieces 	Locking supports To secure the print board and the metal box Made of nylon 4 pieces 	Binding band 	Grommet 

5 Connection Outline

Note for setting the address

- Set the address between 00 and 47 for the previous Super Link connection and between 000 and 127 for the new Super Link connection. (*1)
- Do not set the address overlapping with those of the other devices in the network. (The default is 000)



(*1) Whether the actual link is either the new Super Link or the previous Super Link depends on the models of the connected outdoor and indoor units. Consult the agent or the dealer.

3 Function

Allowing the center console SL1N-E, SL2N-E, and SL3N-AE/BE to control and monitor the commercial air conditioning unit.

4 Control switching

Settings can be changed by the switch SW3 on the SL E board as in the following.

Switch	Symbol	Switch	Remarks
SW3	1	ON	Master
		OFF (default)	Slave
	2	ON	Fixed previous protocol
		OFF (default)	Automatic adjustment of Super Link protocol
	3	ON	Indicates the forced operation stop when abnormality has occurred.
		OFF (default)	Indicates the status of running/stop as it is, when abnormality has occurred.
	4	ON	The hundredth address activated "1"
		OFF (default)	The hundredth address activated "0"


Signal line specification

Communication method	Previous Super Link	New Super Link
Line type	MVVS	MVVS
Line diameter	0.75 - 1.25mm ²	0.75/1.25mm ²
Signal line (total length)	up to 1000m	up to 1500/1000m (*2)
Signal line (maximum length)	up to 1000m	up to 1000m

(*2) Up to 1500 m for 0.75 mm², and up to 1000 m for 1.25 mm². Do not use 2.0 mm². It may cause an error.


(*3) Connect grounding on both ends of the shielding wire. For the grounding method, refer to the section "6 Installation".

- (1) Set the Super Link network address with SW1 (tens place), SW2 (ones place), and SW3 (hundreds place).
- (2) Set the SL E board SW3-1 to be ON (Master) when using this without any remote control (no wired remote control nor wireless remote control).
- (3) Set up the plural master/slave device using the dip switches on the indoor unit board.
- (4) Set up the remote control master/slave device using the slide switch on the remote control board.
- (5) Set up "0" to "F" using the address rotary switch on the indoor unit board when controlling the indoor unit with the multiple remote control.




6 Installation


- When using the metal box (mounted on the indoor unit / mounted on the back of the remote control):
 - (1) Mount the SL E board in the metal box using the locking supports.
 - (2) Wiring should go through the provided grommet since then through the wiring to the hole on the Metal box.
Secure the grommet after inserting the grommet into the Metal box as shown in below figure, then tie the wiring at the outlet of the unit using a binding band.




- ▲ When installed outside the indoor unit, put the metal cover on.



- ▲ When installed on the back of the remote control, mount it directly on the remote control bottom case.




Connect grounding. Connect grounding for the power line to Ground ①, and grounding for the signal line to Ground ② or to the Ground on the indoor unit control box.



- When connecting to the indoor unit control box (ceiling-concealed type and FDT type only):

- (1) Mount the SL E board in the control box using the locking supports.
- (2) Remove 6 bands from the box and put the wiring through the bands to be secured.



Electrical shock hazard! Make sure to turn the power off for servicing. Be cautious so that no abnormal force should be applied to the wiring. Do not let the SL E board hung by the wiring. Do not damage the board with a screw driver.
The board is sensitive to static electricity. Release the static electricity of your body before servicing.
(you can do this by touching the control board which is grounded).

Location of installation

Install the device at the location where there are no electromagnetic waves nor where there is water and dust. The specified temperature range of the device is 0 to 40°C. Install the device at the location where the ambient temperature stays within the range. If it exceeds the specification, make sure to provide solution such as installing a cooling fan. When used outside of the range, it may cause abnormal operation.

7 Indicator display

Check the LED 3 (green) and LED 2 (red) on the SL E board for flashing.

SL E board LEDs		Inspection mode	Display on the integrated network control device
Red	Green		
Off	Flashing	Normal communication	
Off	Off	<ul style="list-style-type: none"> Disconnection in the remote control communication line (X or Y) Short-circuit in the remote control communication line (between X and Y) Faulty indoor unit remote control power Faulty remote control communication circuit Faulty CPU on SL E board 	No corresponding unit number
One flash	Flashing	<ul style="list-style-type: none"> Disconnection in the Super Link signal line (A or B) Short-circuit in the Super Link signal line (between A and B) Faulty Super Link signal circuit 	
Two flashes	Flashing	<ul style="list-style-type: none"> Faulty address setting for the SL E board (Set up the address for previous SL E board : more than 48 new SL E board : more than 128) 	
Three flashes	Flashing	<ul style="list-style-type: none"> SL E board parent not set up when used without a remote control Faulty remote control communication circuit 	E1
Four flashes	Flashing	<ul style="list-style-type: none"> Address overlapping for the SL E board and the Super Link network connected indoor unit 	E2
Off	Flashing	<ul style="list-style-type: none"> Number of connected devices exceeds the specification for the multiple indoor unit control 	E10

PJZ012D029C

10. TECHNICAL INFORMATION

Model SRK20ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK20ZM-S		Average(mandatory)		Yes	
Outdoor unit model name		SRC20ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					

Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	2.00	kW	cooling	SEER	7.00	A++
heating / Average	Pdesignh	2.80	kW	heating / Average	SCOP/A	4.05	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)	Pdh	2.41	kW	heating / Average (-10°C)	elbu	0.39	kW
heating / Warmer (2°C)	Pdh	-	kW	heating / Warmer (2°C)	elbu	-	kW
heating / Colder (-22°C)	Pdh	-	kW	heating / Colder (-22°C)	elbu	-	kW

Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C	Pdc	2.00	kW	Tj=35°C	EERd	4.55	-
Tj=30°C	Pdc	1.47	kW	Tj=30°C	EERd	7.20	-
Tj=25°C	Pdc	1.33	kW	Tj=25°C	EERd	10.40	-
Tj=20°C	Pdc	1.87	kW	Tj=20°C	EERd	10.80	-

Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	2.48	kW	Tj=-7°C	COPd	2.40	-
Tj=2°C	Pdh	1.51	kW	Tj=2°C	COPd	4.20	-
Tj=7°C	Pdh	1.34	kW	Tj=7°C	COPd	5.50	-
Tj=12°C	Pdh	1.56	kW	Tj=12°C	COPd	6.70	-
Tj=bivalent temperature	Pdh	2.48	kW	Tj=bivalent temperature	COPd	2.40	-
Tj=operating limit	Pdh	2.30	kW	Tj=operating limit	COPd	2.10	-

Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-

Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C	Pdh	-	kW	Tj=-7°C	COPd	-	-
Tj=2°C	Pdh	-	kW	Tj=2°C	COPd	-	-
Tj=7°C	Pdh	-	kW	Tj=7°C	COPd	-	-
Tj=12°C	Pdh	-	kW	Tj=12°C	COPd	-	-
Tj=bivalent temperature	Pdh	-	kW	Tj=bivalent temperature	COPd	-	-
Tj=operating limit	Pdh	-	kW	Tj=operating limit	COPd	-	-
Tj=-15°C	Pdh	-	kW	Tj=-15°C	COPd	-	-

Bivalent temperature				Operating limit temperature			
heating / Average	Tbiv	-7	°C	heating / Average	Tol	-15	°C
heating / Warmer	Tbiv	-	°C	heating / Warmer	Tol	-	°C
heating / Colder	Tbiv	-	°C	heating / Colder	Tol	-	°C


Cycling interval capacity				Cycling interval efficiency			
for cooling	Pcycc	-	kW	for cooling	EERcyc	-	-
for heating	Pcyh	-	kW	for heating	COPcyc	-	-

Degradation coefficient				Degradation coefficient			
cooling	Cdc	0.25	-	heating	Cdh	0.25	-

Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode	Poff	5	W	cooling	Qce	101	kWh/a
standby mode	Psb	5	W	heating / Average	Qhe	968	kWh/a
thermostat-off mode	Pto	15	W	heating / Warmer	Qhe	-	kWh/a
crankcase heater mode	Pck	0	W	heating / colder	Qhe	-	kWh/a

Capacity control(indicate one of three options)				Other items			
fixed	No			Sound power level(indoor)	Lwa	49	dB(A)
staged	No			Sound power level(outdoor)	Lwa	59	dB(A)
variable	Yes			Global warming potential	GWP	1975	kgCO2eq.
				Rated air flow(indoor)	-	468	m3/h
				Rated air flow(outdoor)	-	1770	m3/h

Contact details for obtaining more information	Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom						
--	---	--	--	--	--	--	--

B	RWA000Z253	
---	------------	---


Model SRK25ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK25ZM-S		Average(mandatory)		Yes	
Outdoor unit model name		SRC25ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	2.50	kW	cooling	SEER	7.10	A++
heating / Average	Pdesignh	2.90	kW	heating / Average	SCOP/A	4.16	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh	2.48 kW	heating / Average (-10°C)		elbu	0.42 kW
heating / Warmer (2°C)		Pdh	- kW	heating / Warmer (2°C)		elbu	- kW
heating / Colder (-22°C)		Pdh	- kW	heating / Colder (-22°C)		elbu	- kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc	2.50 kW	Tj=35°C		EERd	4.03 -
Tj=30°C		Pdc	1.84 kW	Tj=30°C		EERd	6.55 -
Tj=25°C		Pdc	1.35 kW	Tj=25°C		EERd	10.50 -
Tj=20°C		Pdc	1.91 kW	Tj=20°C		EERd	11.00 -
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	2.57 kW	Tj=-7°C		COPd	2.50 -
Tj=2°C		Pdh	1.56 kW	Tj=2°C		COPd	4.30 -
Tj=7°C		Pdh	1.35 kW	Tj=7°C		COPd	5.60 -
Tj=12°C		Pdh	1.57 kW	Tj=12°C		COPd	6.80 -
Tj=bivalent temperature		Pdh	2.57 kW	Tj=bivalent temperature		COPd	2.50 -
Tj=operating limit		Pdh	2.33 kW	Tj=operating limit		COPd	2.20 -
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	- kW	Tj=-7°C		COPd	- -
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Tj=-15°C		Pdh	- kW	Tj=-15°C		COPd	- -
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv	-7 °C	heating / Average		Tol	-15 °C
heating / Warmer		Tbiv	- °C	heating / Warmer		Tol	- °C
heating / Colder		Tbiv	- °C	heating / Colder		Tol	- °C
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc	- kW	for cooling		EERcyc	- -
for heating		Pcyh	- kW	for heating		COPEcyc	- -
Degradation coefficient				Degradation coefficient			
cooling		Cdc	0.25 -	heating		Cdh	0.25 -
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff	5 W	cooling		Qce	124 kWh/a
standby mode		Psb	5 W	heating / Average		Qhe	977 kWh/a
thermostat-off mode		Pto	17 W	heating / Warmer		Qhe	- kWh/a
crankcase heater mode		Pck	0 W	heating / colder		Qhe	- kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa	50 dB(A)
staged		No		Sound power level(outdoor)		Lwa	60 dB(A)
variable		Yes		Global warming potential		GWP	1975 kgCO2eq.
				Rated air flow(indoor)		-	474 m3/h
				Rated air flow(outdoor)		-	1926 m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative.					
		Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

B RWA000Z253A


Model SRK35ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK35ZM-S					
Outdoor unit model name		SRK35ZM-S					
Function(indicate if present)				Average(mandatory)			
cooling		Yes		Warmer(if designated)		No	
heating		Yes		Colder(if designated)		No	
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	3.50	kW	cooling	SEER	7.10	A++
heating / Average	Pdesignh	3.20	kW	heating / Average	SCOP/A	4.17	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh	2.78 kW	heating / Average (-10°C)		elbu	0.42 kW
heating / Warmer (2°C)		Pdh	- kW	heating / Warmer (2°C)		elbu	- kW
heating / Colder (-22°C)		Pdh	- kW	heating / Colder (-22°C)		elbu	- kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc	3.50 kW	Tj=35°C		EERd	3.47 -
Tj=30°C		Pdc	2.58 kW	Tj=30°C		EERd	5.70 -
Tj=25°C		Pdc	1.66 kW	Tj=25°C		EERd	10.90 -
Tj=20°C		Pdc	2.08 kW	Tj=20°C		EERd	12.80 -
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	2.83 kW	Tj=-7°C		COPd	2.40 -
Tj=2°C		Pdh	1.72 kW	Tj=2°C		COPd	4.30 -
Tj=7°C		Pdh	1.47 kW	Tj=7°C		COPd	5.80 -
Tj=12°C		Pdh	1.73 kW	Tj=12°C		COPd	7.10 -
Tj=bivalent temperature		Pdh	2.83 kW	Tj=bivalent temperature		COPd	2.40 -
Tj=operating limit		Pdh	2.70 kW	Tj=operating limit		COPd	2.20 -
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	- kW	Tj=-7°C		COPd	- -
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Tj=-15°C		Pdh	- kW	Tj=-15°C		COPd	- -
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv	-7 °C	heating / Average		Tol	-15 °C
heating / Warmer		Tbiv	- °C	heating / Warmer		Tol	- °C
heating / Colder		Tbiv	- °C	heating / Colder		Tol	- °C
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc	- kW	for cooling		EERcyc	- -
for heating		Pcyh	- kW	for heating		COPEcyc	- -
Degradation coefficient				Degradation coefficient			
cooling		Cdc	0.25 -	heating		Cdh	0.25 -
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff	7 W	cooling		Qce	173 kWh/a
standby mode		Psb	7 W	heating / Average		Qhe	1074 kWh/a
thermostat-off mode		Pto	27 W	heating / Warmer		Qhe	- kWh/a
crankcase heater mode		Pck	0 W	heating / colder		Qhe	- kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa	58 dB(A)
staged		No		Sound power level(outdoor)		Lwa	62 dB(A)
variable		Yes		Global warming potential		GWP	1975 kgCO2eq.
				Rated air flow(indoor)		-	606 m3/h
				Rated air flow(outdoor)		-	1890 m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative. Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

B RWA000Z253 

Model SRK50ZM-S

Information to identify the model(s) to which the information relates to:				If function includes heating: Indicate the heating season the information relates to. Indicated values should relate to one heating season at a time. Include at least the heating season 'Average'.			
Indoor unit model name		SRK50ZM-S		Average(mandatory)		Yes	
Outdoor unit model name		SRC50ZM-S		Warmer(if designated)		No	
Function(indicate if present)				Colder(if designated)		No	
cooling		Yes					
heating		Yes					
Item	symbol	value	unit	Item	symbol	value	class
Design load				Seasonal efficiency and energy efficiency class			
cooling	Pdesignc	5.00	kW	cooling	SEER	6.30	A++
heating / Average	Pdesignh	4.70	kW	heating / Average	SCOP/A	4.20	A+
heating / Warmer	Pdesignh	-	kW	heating / Warmer	SCOP/W	-	-
heating / Colder	Pdesignh	-	kW	heating / Colder	SCOP/C	-	-
				unit			
Declared capacity at outdoor temperature Tdesignh				Back up heating capacity at outdoor temperature Tdesignh			
heating / Average (-10°C)		Pdh	4.13 kW	heating / Average (-10°C)		elbu	0.57 kW
heating / Warmer (2°C)		Pdh	- kW	heating / Warmer (2°C)		elbu	- kW
heating / Colder (-22°C)		Pdh	- kW	heating / Colder (-22°C)		elbu	- kW
Declared capacity for cooling, at indoor temperature 27(19)°C and outdoor temperature Tj				Declared energy efficiency ratio, at indoor temperature 27(19)°C and outdoor temperature Tj			
Tj=35°C		Pdc	5.00 kW	Tj=35°C		EERd	3.23 -
Tj=30°C		Pdc	3.68 kW	Tj=30°C		EERd	5.30 -
Tj=25°C		Pdc	2.37 kW	Tj=25°C		EERd	8.85 -
Tj=20°C		Pdc	3.08 kW	Tj=20°C		EERd	9.30 -
Declared capacity for heating / Average season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Average season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	4.16 kW	Tj=-7°C		COPd	2.40 -
Tj=2°C		Pdh	2.53 kW	Tj=2°C		COPd	4.40 -
Tj=7°C		Pdh	1.92 kW	Tj=7°C		COPd	5.75 -
Tj=12°C		Pdh	2.84 kW	Tj=12°C		COPd	6.30 -
Tj=bivalent temperature		Pdh	4.16 kW	Tj=bivalent temperature		COPd	2.40 -
Tj=operating limit		Pdh	4.09 kW	Tj=operating limit		COPd	2.20 -
Declared capacity for heating / Warmer season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Warmer season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Declared capacity for heating / Colder season, at indoor temperature 20°C and outdoor temperature Tj				Declared coefficient of performance / Colder season, at indoor temperature 20°C and outdoor temperature Tj			
Tj=-7°C		Pdh	- kW	Tj=-7°C		COPd	- -
Tj=2°C		Pdh	- kW	Tj=2°C		COPd	- -
Tj=7°C		Pdh	- kW	Tj=7°C		COPd	- -
Tj=12°C		Pdh	- kW	Tj=12°C		COPd	- -
Tj=bivalent temperature		Pdh	- kW	Tj=bivalent temperature		COPd	- -
Tj=operating limit		Pdh	- kW	Tj=operating limit		COPd	- -
Tj=-15°C		Pdh	- kW	Tj=-15°C		COPd	- -
Bivalent temperature				Operating limit temperature			
heating / Average		Tbiv	-7 °C	heating / Average		Tol	-15 °C
heating / Warmer		Tbiv	- °C	heating / Warmer		Tol	- °C
heating / Colder		Tbiv	- °C	heating / Colder		Tol	- °C
Cycling interval capacity				Cycling interval efficiency			
for cooling		Pcycc	- kW	for cooling		EERcyc	- -
for heating		Pcyh	- kW	for heating		COPCyc	- -
Degradation coefficient				Degradation coefficient			
cooling		Cdc	0.25 -	heating		Cdh	0.25 -
Electric power input in power modes other than 'active mode'				Annual electricity consumption			
off mode		Poff	5 W	cooling		Qce	278 kWh/a
standby mode		Psb	5 W	heating / Average		Qhe	1568 kWh/a
thermostat-off mode		Pto	40 W	heating / Warmer		Qhe	- kWh/a
crankcase heater mode		Pck	0 W	heating / colder		Qhe	- kWh/a
Capacity control(indicate one of three options)				Other items			
fixed		No		Sound power level(indoor)		Lwa	60 dB(A)
staged		No		Sound power level(outdoor)		Lwa	61 dB(A)
variable		Yes		Global warming potential		GWP	1975 kgCO2eq.
				Rated air flow(indoor)		-	678 m3/h
				Rated air flow(outdoor)		-	2160 m3/h
Contact details for obtaining more information		Name and address of the manufacturer or of its authorised representative.					
		Mitsubishi Heavy Industries Air-Conditioning Europe, Ltd. 7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom					

B RWA000Z253 

INVERTER WALL MOUNTED TYPE RESIDENTIAL AIR-CONDITIONERS



Air-Conditioning & Refrigeration Systems

16-5, Konan 2-chome, Minato-ku, Tokyo, 108-8215 Japan

<http://www.mhi.co.jp>

Because of our policy of continuous improvement, we reserve the right to make changes in all specifications without notice.

© Copyright MITSUBISHI HEAVY INDUSTRIES, LTD.